

SIEMENS

SIMATIC

Communications processor CP 340 PtP Printer Driver

Getting Started

04/2005

A5E00369899-01

Safety Guidelines

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring to property damage only have no safety alert symbol. These notices shown below are graded according to the degree of danger.



Danger

indicates that death or severe personal injury **will** result if proper precautions are not taken.



Warning

indicates that death or severe personal injury **may** result if proper precautions are not taken.



Caution

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

Caution

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

Notice

indicates that an unintended result or situation can occur if the corresponding information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The device/system may only be set up and used in conjunction with this documentation. Commissioning and operation of a device/system may only be performed by **qualified personnel**. Within the context of the safety notes in this documentation qualified persons are defined as persons who are authorized to commission, ground and label devices, systems and circuits in accordance with established safety practices and standards.

Prescribed Usage

Note the following:



Warning

This device may only be used for the applications described in the catalog or the technical description and only in connection with devices or components from other manufacturers which have been approved or recommended by Siemens. Correct, reliable operation of the product requires proper transport, storage, positioning and assembly as well as careful operation and maintenance.

Trademarks

All names identified by ® are registered trademarks of the Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Copyright Siemens AG 2005. All rights reserved.

The distribution and duplication of this document or the utilization and transmission of its contents are not permitted without express written permission. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Siemens AG
Automation and Drives
Postfach 4848, 90327 Nuremberg, Germany

© Siemens AG 2005
Technical data subject to change

First Steps in Commissioning

Preface

These instructions show you how to output messages from a CP 340 to a printer step-by-step on the basis of a concrete example. In the process you also get to know the basic functions of the CP 340 printer driver.

The time required amounts to one to two hours, depending on your experience, plus the time required for procurement, wiring and supply with auxiliary power.



Warning

As a component of plants or systems your PLC requires special rules and regulations to be observed, depending on the field of use.

The non-compliance with these regulations could result in severe injury as well as damage to machines and equipment.

Observe the applicable regulations on safety and the prevention of accidents, for example IEC 204 (EMERGENCY-OFF equipment).



Warning

You may come into contact with live cables and wires if the power supply module of your PLC is activated or if the supply cable is connected to the power system.

Only wire your PLC when it is de-energized.

Requirements

- You have an S7-300 station consisting of
 - Rack
 - Power supply unit
 - CPU
 - CP 340 with RS 232C port and printer option
- You have an IBM-compatible printer with RS 232 interface. The printer is prepared for serial data transfer and is connected by means of an RS 232 connecting cable to the CP 340.
An appropriate configuration of the printer should only be carried out by specialist personnel.
- STEP 7 V5.1+ Service pack 2 are installed correctly on the programming device. Ensure that all the components are compatible, starting from the operating system + service pack up to the STEP7 package + service pack + hotfix and the version of the configuration software with its updates.
- You have set up a printer output sample project for the S7-300 station.
- The programming device is connected to the CPU of the PLC.




Figure 1-1 Example setup

- ① Power supply unit
- ② CPU 3xx
- ③ CP 340
- ④ RS 232 connecting cable / CP 340 - printer
- ⑤ IBM-compatible printer
- ⑥ Programming device
- ⑦ MPI connecting cable / CPU - programming device
- ⑧ S7-300 station

Purpose of the Getting Started Document

The purpose of the Getting Started document is to output the following messages at the following printer:

- At xx:xx:xx.xxx the value reached the limit of 1500 liters
- At xx:xx:xx.xxx the value exceeded the limit of 1500 liters
- At xx:xx:xx.xxx the value dropped below the limit of 1500 liters

Whereby xx:xx:xx.xxx is the current time of day.

The messages are created in this Getting Started by using a format string with 3 variables:

Format string: At %Z the value %Z the limit of %i liters

Message: At xx:xx:xx.xxx the value reached the limit of 1500 liters

Variable 1: Time of day _____
 Variable 2: Configured message No. 0 _____
 Variable 3: Integer value 1500 _____

Whereby:

- %Z: Is the conversion instruction for the data type TIME_OF_DAY
- %i: Is the conversion instruction for the data type INT, WORD, DINT, DWORD
- %N: Is the conversion instruction for outputting a message configured in HW Config

In this Getting Started

- The format string is defined by the DB 10,
- The variables 1, 2 and 3 are defined by the DBs 6, 7 and 8,
- The DB 5 contains the pointer DB, the pointers to the DBs 6 to 10.

1. Step: Installing the configuration software on the programming device

The configuration software contains the function blocks required to connect to your user program as well as programming examples.

The configuration software can be found alternatively

- On the supplied CD
- In the Internet at: <http://www.ad.siemens.de/simatic-cs> Contribution ID: 12310504

Step	Action	Result
1	Start the installation program by double-clicking the file called SETUP.EXE in the SETUP folder.	The installation program is started.
2	Follow the instructions issued by the installation program.	

2. Step: configure the CP 340

Step	Action	Result
1	Open your project in the SIMATIC Manager.	
2	In your project, call the HWCONFIG configuration table.	
3	Double-click on the CP340 RS232C.	The dialog box "CP 340-RS232C properties" opens.
4	Note the module address in the "Addresses" tab. This value is required as a parameter when calling the FB P_PRINT in your user program.	
5	Click on the Parameters command button.	The dialog box "Configure point-to-point coupling CP 340-RS232C" opens.
6	Select the protocol PRINTER and confirm with Yes .	The printer protocol is loaded with the following default settings: 9600 bits/s, 8 data bits, 1 stop bit, parity even, no data flow control, activate BREAK monitoring .
7	Double-click on the Protocol envelope.	The "Protocol" dialog box opens.
8	If necessary, adapt the default protocol settings to your printer protocol and confirm with OK .	
9	Double click the page layout .	The "Page layout" dialog box opens.
10	Specify the page layout and confirm with OK .	
11	Double click on Messages and then SDB .	The "Messages" dialog box opens.
12	Assign a name consisting of a maximum of 8 ASCII characters for the text SDB.	
13	Enter the following message numbers and message texts consecutively at "Edit message:" and click the Enter command button after each entry.	
	Number	Text
	0	reached
	1	exceeded
	2	dropped below
14	Click the command buttons OK and SDB .	The "Messages" dialog box closes.
15	Save the configuration with File > Save and exit the configuration dialog box with File > Exit .	
16	In the "Properties CP 340-RS232C" dialog box click on the OK command button.	
17	Save the configuration you have created with Station > Save and compile in your project.	
18	Transfer the configuration with the CPU in STOP mode by choosing PLC > Download to Module .	The data are transferred directly to the CPU and the CP 340. The "SF" LED goes out to indicate the successful completion of downloading.
19	Use Station > Exit to close the HW Config.	

3. Step: creating blocks in the block folder

Step	Action	Result														
1	In SIMATIC Manager use File > Open ... > Libraries in the catalog Siemens\STEP7\S7libs\CP PtP to open the blocks folder CP 340 and its blocks container.	A two-section window is opened with the title of the library and the FBs and FCs belonging to the CP 340.														
2	Copy the FB 4 into the block folder of your project.															
3	In SIMATIC Manager use File > Open ... > Libraries in the catalog Siemens\STEP7\S7libs\StdLib30 to open the blocks folder IEC Function Blocks and its blocks container.	A two-section window is opened with the title of the library and the IEC functions.														
4	Copy the FC 8 into the block folder of your project.															
5	In SIMATIC Manager use File > Open ... > Libraries in the catalog Siemens\STEP7\S7libs\StdLib30 to open the blocks folder IEC Function Blocks and its blocks container.	A two-section window is opened with the title of the library and the SFBs and SFCs.														
6	Copy the SFC 1 into the block folder of your project.															
7	In the blocks container of your project, use Insert > S7 block > Data blocks the following data blocks:															
	<table border="1"> <thead> <tr> <th>DB</th> <th>Meaning in the Printer output project</th> </tr> </thead> <tbody> <tr> <td>DB 5</td> <td>Pointer DB</td> </tr> <tr> <td>DB 6</td> <td>DB for the Variable 1</td> </tr> <tr> <td>DB 7</td> <td>DB for the Variable 2</td> </tr> <tr> <td>DB 8</td> <td>DB for the Variable 3</td> </tr> <tr> <td>DB 9</td> <td>DB for the Variable 4</td> </tr> <tr> <td>DB 10</td> <td>DB for the format string</td> </tr> </tbody> </table>	DB	Meaning in the Printer output project	DB 5	Pointer DB	DB 6	DB for the Variable 1	DB 7	DB for the Variable 2	DB 8	DB for the Variable 3	DB 9	DB for the Variable 4	DB 10	DB for the format string	
DB	Meaning in the Printer output project															
DB 5	Pointer DB															
DB 6	DB for the Variable 1															
DB 7	DB for the Variable 2															
DB 8	DB for the Variable 3															
DB 9	DB for the Variable 4															
DB 10	DB for the format string															
8	In the blocks container of your project, use Insert > S7 block > Variable table to create the variable table VAT_1.															

4. Step: calling blocks in the OB 1

Step	Action			
1	In your project open the OB 1.			
2	In the declaration table create the variable of the data type DATE_AND_TIME called "Time".			
3	In the OB 1 call the SFC 1, the FC 8 and the FB 4 and assign parameters to the blocks as follows:			
	CALL	"READ_CLK"	SFC1	//Read date and time
	RET_VAL	:=MW3		
	CDT	:= #Time		Enter //date and time in the "Time" variable
	CALL	"DT_TOD"	FC8	//Convert the date and time into the time of day
	IN	:= #Time		
	RET_VAL	:= DB6.DBDO		//Placeholder for the time of day (Variable 1 in the DB 6)
	CALL	"P_PRINT", DB4	FB4	//FB for the printer output of message texts
	REQ	:=M1.0		Trigger bit, positive edge required
	R	:=		//Reset bit
	LADDR	:= 256		//Module address of the CP 340 (from HW Config)
	DB_NO	:= 5		//Number of the Pointer DB
	DBB_NO	:= 0		//Offset in the Pointer DB
	DONE	:= M1.1		//Job finished without errors
ERROR	:= M1.2		//Job finished with errors	
STATUS	:= MW2		//Specification of the error	
4	Save the OB 1 with File > Save .			

5. Step: specifying the data structure of the blocks (also refer to the manual, section "Outputting Message Texts to a Printer")

Now specify the data structure of the blocks DB 5 to 10 and enter the initial values.

Note

Please observe the following points when entering and changing initial values in data blocks:

1. Enter the initial values in the Declaration view of the data blocks.
2. Use **Data > View** to change over to the Data view.
3. Initialize the data blocks with **Edit > Initialize Data Block**.

Table 1-1 Data structure of the DB 5 (pointer DB):

Address	Name	Type	Initial value	Remark
		STRUCT		
+0.0	DB_VAR1	ARRAY[0..2]	6, 0, 4	Pointer to the DB 6 with offset 0 and length 4(DB 6 = DB for the Variable 1: "Time of day")
*2.0		INT		
+6.0	DB_VAR2	ARRAY[0..2]	7, 0, 2	Pointer to the DB 7 with offset 0 and length 2(DB 7 = DB for the Variable 2: "1500")
*2.0		INT		
+12.0	DB_VAR3	ARRAY[0..2]	8, 0, 1	Pointer to the DB 8 with offset 0 and length 1(DB 8 = DB for the Variable 3: "Number of the configured message")
*2.0		INT		
+18.0	DB_VAR4	ARRAY[0..2]	0, 0, 0	DB No. 0: The pointer is interpreted as non-existing and is skipped. Variable 4 is not used.
*2.0		INT		
+24.0	DB_String	ARRAY[0..2]	10, 2, 41	Pointer to the DB 10 with offset 2 and length 41(DB 10 = DB for the format string); The specification offset 2 is necessary, since the length information of the string is contained in the Byte 0 and 1. The length (in this case 41) must correspond to the number of characters which are entered at "Initial value" in the format string (in this case DB 10).
*2.0		INT		
=30.0		END_STRUCT		

Save the DB 5 with **File > Save**.

Table 1-2 Data structure of the DB 6 for the Variable 1:

Address	Name	Type	Initial value	Remark
0.0		STRUCT		
+0.0	DB_VAR	TIME_OF_DAY	TOD#0:0:0.0	Time of day
=4.0		END_STRUCT		

Save the DB 6 with **File > Save**.

Table 1-3 Data structure of the DB 7 for the Variable 2:

Address	Name	Type	Initial value	Remark
0.0		STRUCT		
+0.0	DB_VAR	INT	1500	Limit 1500 liters
=2.0		END_STRUCT		

Save the DB 7 with **File > Save**.

Table 1-4 Data structure of the DB 8 for the Variable 3:

Address	Name	Type	Initial value	Remark
0.0		STRUCT		
+0.0	DB_VAR	Byte	B#16#0	0 = Number of the configured message(Text of Message No. 0 = "reached")
=2.0		END_STRUCT		

Save the DB 8 with **File > Save**.

Table 1-5 Data structure of the DB 9 for the Variable 4:

Address	Name	Type	Initial value	Remark
0.0		STRUCT		
+0.0	DB_VAR	Byte	0	DB 9 for the Variable 4 is not used.
=2.0		END_STRUCT		

Save the DB 9 with **File > Save**.

Table 1-6 Data structure of the DB 10 for the format string:(also refer to the manual, section "Conversion and Control Statements for Printer Output")

Address	Name	Type	Initial value	Remark
0.0		STRUCT		
+0.0	DB_VAR	STRING[41]	'At %Z the value %N the limit of %i liters'	%Z: variable 1 in the format string (time of day) %i: variable 2 in the format string (1500) %N: variable 3 in the format string (number of configured message) The format string entered at Initial value comprises 41 characters (including the blanks). The following applies for the string length to be specified at the type: Number of characters at the initial value ≤ string length at type ≤ 254
=2.0		END_STRUCT		

Save the DB 10 with **File > Save**.

6. Step: creating the variable table

Open the variable table VAT_1 and carry out the following entries:

	Address	Symbol	Display format	Status value	Modify value	Remarks
1	M 1.0		BIN		2#0	Trigger bit (0-1 edge required)
2	M 1.1		BIN			
3	M 1.2		BIN			
4	DB6.DBDO		TIME			Current time of day
5	MW 2		HEX			
6	DB8.DBB0		HEX		B#16#00	Number of the configured message

Save the variable table VAT_1 with **Table > Save**.

7. Step: downloading the program

Step	Action
1	In SIMATIC Manager in your project select the blocks container.
2	In the STOP state of the CPU, download these blocks to your CPU by using PLC > Load .
3	Switch the CPU to the RUN state.

8. Step: testing the program

Step	Action	Result
1	In the variable table switch to online by using PLC > Create connection to > Configured CPU.>	
2	Switch to monitor mode with Variable > Observe.	You can observe the current time of day at the status value of the address DB6.DBD0.
3	Create 0–1 edges at the address M 1.0, the trigger bit for the FB 4, by alternatively entering 0 and 1 as the modify value and making hte respective modify value valid by using Variable > Modify value activate.	At every 0–1 edge on the trigger bit, the following message is output at the printer: At xx:xx:xx.xxx the value reached the limit of 1500 liters.
4	At the address DB8.DBB0, change the modify value to 1 and make it valid by using Variable > Modify value activate.	
5	Create 0-1 edges at the address M 1.0	At every 0–1 edge on the trigger bit, the following message is output at the printer: At xx:xx:xx.xxx the value reached the limit of 1500 liters.
6	At the address DB8.DBB0, change the modify value to 2 and make it valid by using Variable > Modify value activate.	
7	Create 0-1 edges at the address M 1.0	At every 0–1 edge on the trigger bit, the following message is output at the printer: At xx:xx:xx.xxx the value reached the limit of 1500 liters.