

PCS 7 Minimal Configurations

SIMATIC PCS 7 V8.0 SP1

Application Description • September 2013

Applications & Tools

Answers for industry.

SIEMENS

Siemens Industry Online Support

This article is taken from the Siemens Industry Online Support. The following link takes you directly to the download page of this document:

<http://support.automation.siemens.com/WW/view/en/24023824>

Caution

The functions and solutions described in this article confine themselves to the realization of the automation task predominantly. Please take into account furthermore that corresponding protective measures have to be taken up in the context of Industrial Security when connecting your equipment to other parts of the plant, the enterprise network or the Internet. Further information can be found under the Item-ID 50203404.

<http://support.automation.siemens.com/WW/view/en/50203404>



SIMATIC PCS 7 V8.0 SP1

PCS 7 Minimal Configurations

Application Description

Minimal Configurations An Overview	1
General/Optional System Settings	2
ES/OS Stand alone Systems	3
ES/OS-Client and OS Server	4
ES, OS-Master and OS Standby	5
ES/OS-Master and OS-Standby	6
Expansion by PCS 7 Web option	7
History	8

Warranty and liability

NOTE

The Application Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly. These application examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time without prior notice.

If there are any deviations between the recommendations provided in these application examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document.

Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Application Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act (“Produkthaftungsgesetz”), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract (“wesentliche Vertragspflichten”). The damages for a breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of Siemens Industry Sector.

Preface

Purpose of this document

Typical PCS 7 systems have at least one ES (Engineering Station) on the PC side, one or more possibly redundant servers, as well as several OS clients (Operator Stations). Apart from the maximum availability of process control and data acquisition, the predominant option here is loading program changes or expansions quickly into the running process with out any interference.

In comparison, small systems or stand alone units tend to work with extremely little maintenance requirements after commissioning. To reaching a high efficiency requires being able to work with as few PC stations as possible. It therefore makes sense to use the rarely used ES as an OS in process mode.

This document is meant as a selection aid during research for the suitable PC configuration for small plants. Various minimal configurations (up to a maximum of three PCs) are compared regarding their functionality. Since the respective PCS 7 configuration is not a focus of the system documentation, the activities necessary for the setup are given in form of detailed step-by-step instructions.

Main contents

The main focus is on the following points:

- Configuration comparison regarding functionality
- Activities for engineering of the various configurations

Table of Contents

Warranty and liability	4
Preface	5
Table of Contents	6
1 Minimal Configurations - An Overview	8
1.1 ES/OS Stand-alone Systems	8
1.2 ES/OS Client and OS Server	9
1.3 ES, OS-Master and OS- Standby	10
1.4 ES/OS-Master and OS-Standby	11
2 General/Optional System Settings	13
2.1 Bus Connection of the PC Stations	13
2.2 WinCC Autostart	13
3 ES/OS Stand-alone Systems	14
3.1 Configuration Description	14
3.2 Required Hardware and Software Licenses	15
3.3 Step-by-step Configuration	16
3.3.1 ES Configuration	16
3.3.2 OS configuration	22
3.3.3 Activating Runtime	24
3.3.4 Particularities at downloading of OS Project Modifications	24
4 ES/OS Client and OS Server	25
4.1 Configuration Description	25
4.2 Required Hardware and Software Licenses	26
4.3 Step-by-step Configuration	27
4.3.1 Preparatory Steps	27
4.3.2 ES Configuration	27
4.3.3 OS Configuration	42
4.3.4 Activating Runtime	47
4.3.5 Particularities at downloading of OS Project Modifications	47
5 ES, OS-Master and OS-Standby	48
5.1 Configuration Description	48
5.2 Required Hardware and Software Licenses	49
5.3 Step-by-step Configuration	50
5.3.1 ES Configuration	50
5.3.2 OS Configuration	65
5.3.3 Activating Runtime	71
6 ES/OS-Master and OS-Standby	72
6.1 Configuration Description	72
6.2 Required Hardware and Software Licenses	75
6.3 Step-by-step Configuration	76
6.3.1 ES Configuration	76
6.3.2 OS Configuration	88
6.3.3 Activating Runtime	95
6.3.4 Particularities at downloading of OS Project Modifications	95
7 Expansion by PCS 7 Web Option	96
7.1 Web Configurations	97
7.2 Web-Specific Hardware and Software Requirements	99

7.3	Maximal number of Web client accesses	100
7.4	Configuration of OS Web server	101
7.4.1	Publishing of Project Data.....	102
7.4.2	Setting of User Rights, Website Start Screen and Language	105
7.4.3	Configuring with the Web Configurator.....	106
7.4.4	Loading and Compiling of Web server.....	109
7.5	Settings on Web client	110
7.6	Installation of Web client plugins	114
8	History	116

1 Minimal Configurations - An Overview

Based upon using the Engineering Station as an Operator Station in process mode, or realizing several OS with as few PCs as possible, various constellations are possible. The following variants were selected according to feasibility and sensibility within the context of PCS 7.


In connection with the configurations shown here, possible solutions are described, where the configurations do not differ considerably.

Generally, when using the engineering computer as OS, certain functionality losses must be taken into account, as for certain activities the OS project must be closed. This will also be discussed below in more detail.

1.1 ES/OS Stand-alone Systems

The smallest of all possible configurations requires only one PC station.

Figure 1-1



Process mode / functionality

Since version 6.1 of PCS 7, the OS project can also be compiled while Runtime is activated (delta compilation). This provides the operator function and archiving functions permanently.

NOTE The description and configuration instruction for this configuration is available in chapter 3 ES/OS Stand-alone Systems.

Alternatives / variations


Alternatively, the complete SIMATIC PCS 7 BOX package is also an option. It combines the AS, the OS and the ES in a compact PC system. A PROFIBUS interface for connecting the decentralized process periphery is also integrated.

NOTE The stand-alone system ES/OS can also be expanded by the PCS 7 OS Web server functionality. The respective instruction can be found in chapter 7 "Expansion by PCS 7 Web Option"

1.2 ES/OS Client and OS Server

With an additional PC station as the OS server, there is the option of using the ES as the OS client. It accesses the data of the OS server in process mode and visualizes the data.

Figure 1-2



Process mode / functionality

For PCS 7, the OS server can be used for operator functions if a maximum of four OS clients are connected. During server failure, however, the complete OS functionality fails in this example. Furthermore, the OS client must be closed for later OS project changes. However, the OS server continues working during compiling/loading of changes.

NOTE The description and configuration instruction for this configuration is available in chapter 4 "ES/OS Client and OS Server".


Alternatives / variations

Another advantage of this configuration is the option of connecting further clients to the OS server in a relative simple and cost-effective way.

1.3 ES, OS-Master and OS- Standby

The PCS 7-conform realization of the OS redundancy requires three PC stations. The ES then only fulfills engineering tasks and is only used for testing OS functions during that time.

Figure 1-3



Process mode / functionality

Since the ES is not involved in the process mode, the operator functions of both OS Single Stations are permanently available. Even during a complete download of project changes, one OS always remains active. The redundancy provides for mutual synchronization. Online as well as after failure of one of the partners.

The COM-Cable (RS 232 Connection) is used for optimization of internal communication between both OS Single Stations.

From PCS 7 V7.0 it is also possible to implement the redundancy connection via an Industrial Ethernet connection (BCE or CP1613/CP1623) instead of the COM connection.

NOTE The description and configuration instruction for this configuration is available in chapter 5 “ES, OS-Master and OS- Standby”.

Alternatives / variations


The low-maintenance systems focused on in this documentation often do not require a permanent ES. If a temporary ES is hired for configuration, commissioning and project changes.

The theoretical expansion with additional OS clients is not possible without problems in this example, as the two OS have not been installed server operating systems.

1.4 ES/OS-Master and OS-Standby

For this configuration with two redundant OS single-user systems one of both stations is simultaneously used as ES, which saves a separate third station.

Figure 1-4



Process mode / functionality

In this example, both PC stations work as redundant stand-alone OS stations in process mode, which mutually synchronize each other during operation as well as after failure of one of the partners. This also becomes relevant during later OS project changes for which the master OS needs to be terminated. In this case, the standby OS takes on the master role. It continues working during compiling/downloading of the changes and updates the redundancy partner after its return.

The COM-Cable (RS 232 Connection) is used for optimization of internal communication between both OS Single Stations.

From PCS 7 V7.0 it is also possible to implement the redundancy connection via an Industrial Ethernet connection (BCE or CP1613/CP1623) instead of the COM connection.

For a complete download, the OS project must be deactivated and closed on both stations. During this time, no OS functionalities are available.

NOTE

This architecture does not provide the full PCS 7 functionality because the redundancy is setup based on WinCC tools.

The respective restrictions during process operation and differences in system behavior can be found together with description and configuration instruction in chapter 6 "ES/OS-Master and OS-Standby".

Alternatives / variations

In order to achieve a PCS 7-compliant configuration of the OS redundancy, it is recommended to use three PC stations. With the change of the license concept as of PCS 7 V8.0, the same side of license packages is required for this purpose. The configuration of the redundancy with two PC stations is partly limited (see chapter 6.1 Configuration Description) and only saves you one hardware compared to the PCS 7 compliant configuration with one separate ES and two redundant single stations (see chapter "1.3 ES, OS-Master and OS- Standby").

NOTE

The stand-alone system ES/OS can also be expanded by the PCS 7 OS Web server functionality. The respective instruction can be found in chapter 7 "Expansion by PCS 7 Web Option".

2 General/Optional System Settings

The relevant cross-configuration system settings are suggested below.

2.1 Bus Connection of the PC Stations

Plant bus (system bus)

In the ES as well as in each server, a network card in "Configured Mode" is employed for the plantbus. On this network card, only the ISO protocol is activated for Windows. If a CP 1623 exists, it is used as access to the plantbus. The configuration occurs in SIMATIC NetPro and HW Config.

Terminal bus

Apart from the configuration with only one ES/OS single station, all other PC stations are also linked with the terminal bus. The required second network card of ES and the server is set to "PG operation". In SIMATIC NetPro and HW Config this card is not configured. PCS 7 finds this network access via the computer names or the paths for the target computer, which must be entered at the Object Properties of the PC station. For this network card, only the TCP/IP protocol (no ISO) is activated for Windows.

Client-PC stations are generally only equipped with a network card that connects them to the terminal bus. For this network card, only the TCP/IP protocol (no ISO) is activated for Windows.

2.2 WinCC Autostart

This document contains the step-by-step instructions, that the OS project in the WinCC Explorer is opened on the OS servers and clients for the purpose of activating Runtime.

In the system this should be avoided, as normally no configuration licenses (RC licenses) exist on the OS. If the WinCC Explorer is hereby opened for more than two hours, WinCC goes into demo mode and must be closed entirely for further configuration steps (incl. Runtime) and be opened again.

In order to activate Runtime automatically with the computer start-up without opening the WinCC Explorer, an autostart for the project can be configured.

In conjunction with SIMATIC NET Edition 2005 (as from WinCC V6.0 SP3) the WinCC tool "AutoStartRT" should be configured in "Set SIMATIC NET Configuration Console PC station" in order to configure the WinCC Autostart:

<http://support.automation.siemens.com/WW/view/en/23061262>


3 ES/OS Stand-alone Systems

3.1 Configuration Description

The stand-alone system is the smallest possible configuration. The same PC is used for ES and OS functionalities.


Hardware configuration

Figure 3-1



PCS 7 configuration

Figure 3-2



3.2 Required Hardware and Software Licenses

Hardware

The following hardware is recommended for this configuration and can be ordered via the Siemens mall. Your selected operating system and the system software SIMATIC PCS 7 are then preinstalled accordingly.

Table 3-1

Station	Product information	Operating system	Plantbus transition
ES/OS	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows 7	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows 7	CP 1632

Software licenses

In the following please find the software/license package necessary for this configuration selection.

In the selected configuration as a stand-alone system, the number of the POs is restricted to no more than 2000.

Table 3-2

Component	Software/license package
ES/OS	<ul style="list-style-type: none"> • SIMATIC PCS 7 AS/OS Engineering Software V8.0 (PO unlimited) • SIMATIC PCS 7 AS Runtime License (max. 2000 POs) • SIMATIC PCS 7 OS Software Single Station V8.0 • SIMATIC PCS 7 OS Runtime License (max. 2000 POs)

3.3 Step-by-step Configuration

NOTE The following instruction was generated on the basis of Windows 7 and PCS 7 V8.0 SP1.
For the plantbus transition a CP1623 is used as an example.

3.3.1 ES Configuration


Generating the multiproject




As a basis for the following instruction, all PC stations must be physically networked according to Figure 4-1 (S. 14). Furthermore, a multiproject must have been created on the ES in which the AS has already been configured regarding hardware and software.

Generating a PC station

In the PCS 7 project, the PC station is generated, which represents the ES as well as the OS.

Table 3-3



Step	Activity	Screenshot
1.	<p>In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”.</p> <p>Change the name of the PC station so that it corresponds to the name of the local computer in the network.</p>	 <p>The screenshot shows the SIMATIC Manager interface. The 'Component view' is active, showing a project tree with 'K5_MP_MP' selected. A context menu is open over the project, with 'Insert New Object' highlighted. A sub-menu is displayed, listing various station types, with 'SIMATIC PC Station' selected. Other options include SIMATIC 400 Station, SIMATIC 300 Station, SIMATIC H Station, Other Station, SIMATIC SS, PG/PC, MPI, PROFIBUS, Industrial Ethernet, PTP, Foundation Fieldbus, S7 Program, Preconfigured Station..., OS, OS (Client), Shared Declarations, and Project Documentation.</p>




Step	Activity	Screenshot
2.	Open the HW Config of the PC station of the OS server.	
3.	From the object catalog ("View > Catalog"), add a "WinCC Application" and a network card of the type "CP1623".	
4.	<p>Under "Subnet", select the plantbus or create it with the button "New..."</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option "IP protocol is being used".</p> <p>Confirm the settings with "OK".</p>	
5.	Save and compile the configuration via menu item "Station > Save and Compile". Close the HW Config.	

Configuring the PC station

The function “**Configure PC station**” transfers the project configuration to one or more target stations.

Table 3-4

Step	Activity	Screenshot
6.	<p>Configure the component configurator of the ES. Select the PC station of the ES and choose “PLC > Configure...” from the context menu.</p>	 <p>The screenshot shows the 'color_gs_MP (Component view)' window. The left pane displays a project tree with components like 'color_gs_MP', 'color_gs_Phi', 'AS25', 'CPU 417-4', 'CP 443-1', 'CP 443-5 Ext', 'color_gs', and 'color_gs'. The right pane shows a table with columns 'Object name', 'Symbolic name', and 'Type'. A context menu is open over the 'color_gs' component, with the 'PLC' option expanded to show 'Configure...' (Ctrl+K) as the selected item. Other options include 'Download' (Ctrl+L), 'Access Protection', 'Print', 'SIMATIC Route Control', 'SIMATIC BATCH', 'Rename' (F2), and 'Object Properties...' (Alt+Return).</p>
7.	<p>Under “Accessible computers”, choose the PC which is provided for configuration.</p> <p>NOTE If you chose the option “Computer name identical to the PC station name” in the component view “Object Properties” for the PC station, the component configurator directly displays the target computer to be configured.</p> <p>With “Display”, you can have the current configuration of the PC station displayed. Hit the “Configure...” button.</p>	 <p>The screenshot shows the 'Configure' dialog box. It has a title bar with a close button. The 'Local network connection:' dropdown is set to 'Terminalbus'. There is an 'Update' button. The 'Accessible computers:' list contains 'ES60', 'SV60A', and 'SV60B'. A checkbox 'Use configured computer name' is checked. The 'Target computer:' field is set to 'ES60'. There are 'Configure...' and 'Display...' buttons. At the bottom, there is a 'Messages:' text area and 'Close' and 'Help' buttons.</p>



Step	Activity	Screenshot
8.	<p>In the displayed window you see how the PC station is configured. Confirm this with "OK".</p>	
9.	<p>Acknowledge the information with "OK".</p>	
10.	<p>Finally, you receive the following message in the bottom window: "Transfer completed successfully." Close the configuration dialog box.</p>	




Configuration and download of the AS/OS communication

The connection with NetPro is configured below and loaded into the stations.

NOTE For station granular configuration, the subnets of the individual subprojects must be joined beforehand.

Table 3-5

Step	Activity	Screenshot
11.	Open NetPro. Select the WinCC application of the ES and open the context menu. Choose "Insert New Connection".	
12.	In the "Connection Partner" window, select CPU of the AS. Make sure that in the "Connection" field, "S7 connection" has been selected. Confirm the setting with "OK".	

Step	Activity	Screenshot
13.	In the “General” tab, in “Connection identification”, change the “Local ID” into a meaningful name, like AS60. Confirm the entry with “OK”.	
14.	Save and compile “Network” > “Save and Compile...”. Select “Compile and check everything”. Confirm the setting with “OK”.	
15.	Mark the ES and then, over the context menu item load “Download to Current Project > Selected Stations”. Download the AS in the same way. Then close NetPro.	

Copyright © Siemens AG 2013 All rights reserved

Compile and download the user program


Compile the S7 program and download it into the AS.




Compiling the OS project

Prior to that compile the OS project in the SIMATIC Manager.

3.3.2 OS configuration

Table 3-6

Step	Activity	Screenshot
1.	<p>Open the OS project.</p> <p>In the opened WinCC Explorer, open the OS project and select "Properties" in the context menu.</p>	 <p>The screenshot shows the WinCC Explorer interface. The title bar reads 'WinCC Explorer - D:\Projects\KS\KS_MP_M'. The menu bar includes 'File', 'Edit', 'View', 'Tools', and 'Help'. A toolbar with various icons is visible below the menu. The main area displays a tree view of the project structure. The 'OS' folder is expanded, showing sub-items: 'Com', 'Tag', 'Structure tag', 'Graphics Designer', 'Alarm Logging', 'Tag Logging', 'Report Designer', 'Global Script', 'Text Library', 'Text Distributor', 'User Administrator', 'Cross-Reference', 'Redundancy', 'User Archive', 'Time synchronization', 'Horn', 'Picture Tree Manager', 'Lifebeat Monitoring', 'OS Project Editor', 'Component List Editor', 'SFC', and 'Web Navigator'. A context menu is open over the 'Tag' item, with options 'Find...' and 'Properties' visible.</p>

Step	Activity	Screenshot
2.	<p>In the “General” tab under “type:” select “Single-User Project”.</p> <p>Confirm the selection and the message that appears with the “OK” button.</p>	 
3.	Prevent deleting the startup list by pressing the “No” button.	
4.	<p>Close the WinCC Explorer.</p> <p>NOTE The changes will only become effective when the WinCC Explorer has been closed and opened again.</p>	

3.3.3 Activating Runtime

After the OS project has been closed, you can open it again and activate Runtime.

3.3.4 Particularities at downloading of OS Project Modifications

If OS and ES are operated in a computer, no load process must be performed as all of the required data already exists. Here, executing the “Compile OS” function is sufficient.


Analog to the “Download changes” function, the “Compile changes” function can be executed at stand-alone systems without terminating the process mode of the OS.

4 ES/OS Client and OS Server

4.1 Configuration Description


For a server-client structure with only two computers, the ES serves as the OS client at the same time. In the configuration, three PC stations are provided for.

Figure 4-1



PCS 7 configuration

Figure 4-2



4.2 Required Hardware and Software Licenses

Hardware

The following hardware is recommended for this configuration and can be ordered via the Siemens mall. Your selected operating system and the system software SIMATIC PCS 7 is then preinstalled accordingly.

Table 4-1

Component	Product information	Operating system	Plantbus transition
ES/OS Client	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows 7	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows 7	CP 1623
OS Server	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows Server 2008 R2	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows Server 2008 R2	CP 1623

Software licenses

In the following the different software/license packages required for this configuration selection have been listed.

An OS server can provide up to 8500 POs with the respective software package - depending on the scope of the project. In addition to the Engineering Software, an OS client software must be installed on the ES.

Table 4-2

Component	Software/license packages
ES/OS Client	<ul style="list-style-type: none"> • SIMATIC PCS 7 AS/OS Engineering Software V8.0 (PO unlimited) • SIMATIC PCS 7 AS Runtime License (max. 2000 PO) • SIMATIC PCS 7 OS Software Client V8.0
OS Server	<ul style="list-style-type: none"> • SIMATIC PCS 7 OS Software Server V8.0 • SIMATIC PCS 7 OS Runtime License (max. 8500 PO)

4.3 Step-by-step Configuration

Note

The following instruction was generated on the basis of Windows 7 and PCS 7 V8.0 SP1.

For the plantbus transitions, CP1623 is used as an example. A clock synchronization is activated.

The PC stations in the test setup are called:

- ES/OS client: ES60
- OS server: SV60A

4.3.1 Preparatory Steps

Create a project folder in the OS server and release it. You can then transmit OS data configured on the Engineering Station to the OS.

4.3.2 ES Configuration

Generating the multiproject

As a basis for the following instruction, all PC stations must be physically networked according to Figure 4-1 (S.25). Furthermore, a multiproject must have been generated on the ES in which the AS has already been configured regarding hardware and software.

Then you can start with the following CPU and CP settings.



AS settings

This example describes a path where the OS server defines the master time.

NOTE Further options of clock synchronization are described in detail in the Manuals:

- [SIMATIC Process Control System PCS 7 Operator Station \(V8.0\)](#)
- [SIMATIC Process Control System PCS 7 Time synchronization \(V8.0\)](#)

Table 4-3




Step	Activity	Screenshot
1.	Open the HW Config of the AS. Select the CPU and choose “Object Properties...” from the context menu.	
2.	Go to the “Diagnostics/clock” tab. In the section under “Clock”, set “As slave” for the AS under “Synchronization Type”. Confirm the setting with “OK”.	




Step	Activity	Screenshot
3.	Open the context menu of the CP and select "Object Properties...".	
4.	Go to the "Time-of-Day Synchronization" tab. Activate the option "Activate SIMATIC time-of-day synchronization". Confirm the setting with "OK".	
5.	Save and compile the configuration with "Station > Save and Compile". Close the HW Config.	

Generating the ES PC station

In order to be able to test the OS project on the ES, generate a PC station for the ES with WinCC Application.




Table 4-4




Step	Activity	Screenshot
<p>1.</p>	<p>In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”.</p> <p>Change the name of the PC station so that it corresponds to the name of the local computer in the network.</p>	
<p>2.</p>	<p>Open the HW Config of the PC station of the OS server.</p>	
<p>3.</p>	<p>From the object catalog (“View > Catalog”), add a “WinCC Application” and a network card of the type “CP1623”.</p>	





Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP 1623 and select “Object Properties...”.</p>	
6.	<p>Select the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via menu item “Station > Save and Compile”.</p> <p>Close the HW Config.</p>	
8. optional	<p>In the SIMATIC Manager, delete the OS application of the PC station of the ES as it is not required in our example.</p>	

Generating the OS server PC station

Table 4-5




Step	Activity	Screenshot
1.	In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”. You can choose its name freely.	
2.	Open the HW Config of the PC station with the context menu.	
3.	From the object catalog (“View > Catalog”), add a “WinCC Application” and a network card of the type “CP1623”.	



Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New...”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP1623 and select “Object Properties...”.</p>	
6.	<p>Switch to the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via menu item “Station > Save and Compile”.</p> <p>Close the HW Config.</p>	

Step	Activity	Screenshot
8.	<p>In the SIMATIC Manager, open the properties dialog of the OS project of the OS server.</p> <p>Switch to the “Target OS and Standby OS Computer” tab.</p> <p>Under “Standby-OS”, select “<none>”.</p> <p>Then hit the “Search...” button.</p>	
9.	<p>Navigate by the drop down menu to the enable project folder of the OS server (see 4.3.1 Preparatory Steps).</p> <p>Hit the “Save” button.</p>	
10.	<p>Check the selected path and confirm with the “OK” button.</p>	
11.	<p>Acknowledge the information dialog with “Yes”.</p>	

Generating the client PC station

Table 4-6



Step	Activity	Screenshot
1.	In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”. You can choose its name freely.	
2.	Open the HW Config of the PC station of the OS client.	
3.	From the object catalog (“View > Catalog”), add a “WinCC Application Client”.	
4.	Save and compile via menu item “Station > Save and Compile...”. Close the HW Config.	




Step	Activity	Screenshot
5.	Open the context menu of the PC station of the client in the SIMATIC Manager and select "Object Properties".	
6.	Under "Computer name", enter the name of the PC, where the operating of the client shall be carried out. In the configuration on hand, this is the ES computer. Confirm the entry with "OK".	

Configuring all relevant PC stations

The function “Configure PC station” transfers the project configuration to one or more PLCs. First configure the local components configurator of the ES and then the OS connected to the plantbus.

Table 4-7

Step	Activity	Screenshot
1.	<p>Configure the component configurator of the ES. Open the ES context menu and select “PLC > Configure...”.</p>	
2.	<p>Under “Accessible computers”, choose the PC which is provided for configuration.</p> <p>NOTE If you chose the option “Computer name identical to the PC station name” in the component view “Object Properties” for the PC station, the component configurator directly displays the target computer to be configured.</p> <p>With “Display”, you can have the current configuration of the PC station displayed. Hit the “Configure...” button.</p>	



Step	Activity	Screenshot
3.	<p>In the displayed window you see how the PC station is configured. Confirm this setting with "OK".</p>	
4.	<p>Acknowledge the information dialog with "OK".</p>	
5.	<p>Finally, you receive the following message in the bottom window: "Transfer completed successfully." Close the configuration dialog box.</p>	
6.	<p>Please configure the component configurator of the OS server analog to step 1 to 5.</p>	




Configuration and download of the AS/OS communication

In the following, the connections between the PC stations and the AS in NetPro are configured and downloaded into the individual stations.

NOTE For station granular configuration, the subnets of the individual subprojects must be joined beforehand.

Table 4-8

Step	Activity	Screenshot
1.	<p>Open NetPro.</p> <p>Select the WinCC application of the ES and open the context menu. Choose "Insert New Connection".</p>	
2.	<p>In the "Connection Partner" window, select the CPU of the AS.</p> <p>Make sure that in the "Connection" field a "S7 connection" has been selected.</p> <p>In this example, a fault-tolerant S7 connection is configured due to the AS configuration.</p> <p>Confirm the setting with "OK".</p>	

Step	Activity	Screenshot
3.	<p>In the “General” tab, in “Connection identification” change the “Local ID” into a meaningful name, like AS60. Confirm the entries with “OK”.</p>	
4.	<p>Repeat steps 1 to 3 for connecting the OS server to the AS. It is important here, that the connections of the ES and the OS server with the AS have identical names. Then, save and compile the configuration with the menu item “Network > Save and compile...”. Choose the option “Compile and check everything” and confirm with “OK”.</p>	
5.	<p>Select the ES and then download the connections via the context menu “Download to Current Project > Selected Stations”. Download the OS server and the AS in the same way. Then close NetPro.</p>	

Copyright © Siemens AG 2013 All rights reserved

Compile and download the user program

Compile the S7 program and download it into the AS.



Compiling the OS server project

Compile the OS server project in the SIMATIC Manager.

Look out for the correct OS assignment to the server in Plant View.

Assigning the server package

Table 4-9

Step	Activity	Screenshot				
1.	Select the OS application of the OS client and select "Assign OS server..." in the context menu.	 <p>The screenshot shows the SIMATIC Manager interface with the component view open. The tree structure includes 5_MP_MP, 5_MP_Pri, AS60, CL60, WinCC Appl. Client, OS(4), ES60, SV60A, Globale Dekla, and 3_MP_Lib. A context menu is displayed over the OS(4) object, with the 'Assign OS server...' option highlighted.</p>				
2.	Then select the respective OS project and acknowledge with "OK".	 <p>The screenshot shows the 'OS server assignment for OS_Client' dialog box. It contains a table with the following data:</p> <table border="1" data-bbox="874 1122 1347 1489"> <thead> <tr> <th>OS Information</th> <th>Symbolic computer name</th> </tr> </thead> <tbody> <tr> <td><input checked="" type="checkbox"/> 5_MP_Pri - OS_Server</td> <td>SV60A</td> </tr> </tbody> </table> <p>Buttons for 'OK', 'Cancel', and 'Help' are visible at the bottom of the dialog. A status bar at the bottom indicates 'The WinCC project was opened'.</p>	OS Information	Symbolic computer name	<input checked="" type="checkbox"/> 5_MP_Pri - OS_Server	SV60A
OS Information	Symbolic computer name					
<input checked="" type="checkbox"/> 5_MP_Pri - OS_Server	SV60A					

Step	Activity	Screenshot
3.	Confirm the successful download of the package with "OK".	



4.3.3 OS Configuration


Activating the clock synchronization

Still on the ES, the necessary settings are activated in the OS projects by OS server and OS client.

Table 4-10

Step	Activity	Screenshot
1.	Open the OS server project.	



Step	Activity	Screenshot
2.	<p>Open the editor "Time synchronization" with the context menu.</p> <p>Activate the checkbox "Synchronization via System Bus (Master, Slave)".</p> <p>In "Access point 1", select "CP1623(ISO)" and activate the option "Master".</p> <p>Confirm the setting with "OK".</p> <p>NOTE</p> <p>If the ES server, as opposed to the OS server, does not have a CP1623, the settings for the clock synchronization cannot be executed here. The clock synchronization settings must, in this case, be executed on the OS server itself after the download of the OS project.</p>	
3.	Close the OS server project.	
4.	Open the OS client project.	


Step	Activity	Screenshot
5.	<p>Open the editor “Time synchronization” with the context menu.</p> <p>Activate the checkbox “Synchronization via Terminal Bus (Slave)” and select “Use the time from a connected WinCC server”.</p> <p>Confirm the setting with “OK”.</p>	
6.	Close the OS client project.	

Download the OS project to the OS server

After the clock synchronization has been configured on the ES side, the OS project can be downloaded to the OS server.

Table 4-11


Step	Activity	Screenshot
1.	In the SIMATIC Manager, select the OS project of the OS server and select "PLC > Download" from the context menu.	 <p>The screenshot shows the SIMATIC Manager interface. The project tree on the left displays a hierarchy including '5_MP_MP', '5_MP_Pj', 'AS60', 'CL60', 'ES60', 'SV60A', 'WinCC Appl.', and 'OS Server'. A context menu is open over the 'OS Server' project, with the 'PLC' option selected and its sub-menu 'Download' also selected. Other menu items include 'Open Object', 'Cut', 'Copy', 'Paste', 'Delete', 'Insert New Object', 'Compile', 'Display compilation log...', 'Display load log...', 'Generate server data', 'Assign OS server...', 'Start OS simulation', 'Import WinCC objects', 'Print', 'Plant Hierarchy', 'Rename', and 'Object Properties...'.</p>
2.	Downloading the OS project for the first time requires a complete download. Start the download with "OK".	 <p>The screenshot shows the 'Download OS' dialog box. The 'Target system' is set to '\\SV60A\Projects\OS_Server\OS_Server.mcp'. Under the 'Scope' section, 'The entire WinCC project' is selected with a radio button. There is also an option for 'Changes' with a 'Details' button. A checkbox for 'Start compilation before downloading' is currently unchecked. A message at the bottom states: 'The entire WinCC project will be transferred to the runtime OS.' The dialog has 'OK', 'Cancel', and 'Help' buttons at the bottom.</p>

Step	Activity	Screenshot
3.	After the successful download, the OS project is located on the OS server in the intended folder. Confirm this with "OK".	

OS configuration on the OS server

After the first download, the following step-by-step instructions for time synchronization must be checked and corrected if necessary.

Table 4-12

Step	Activity	Screenshot
1.	Open the OS project on the OS server.	
2.	Open the editor "Time synchronization" with the context menu. Activate the checkbox "Synchronization via System Bus (Master, Slave)". In "Access point 1", check or select "CP1623(ISO)" and press the "Master" radio button. Confirm the settings always with "OK".	

4.3.4 Activating Runtime

Open the OS project on the OS server and activate Runtime.
Then change to the ES computer and open the OS client project. Here, activate Runtime, too.

4.3.5 Particularities at downloading of OS Project Modifications

Delta-download

Before OS compilation and download are possible on the ES, the OS client Runtime must be deactivated and the WinCC project must be closed.

Entire download

Before OS compilation and download are possible from the ES, the OS client Runtime as well as the OS server Runtime must be deactivated and the WinCC projects must be closed

5 ES, OS-Master and OS-Standby


5.1 Configuration Description

During process operation the server pair runs completely in parallel and absolutely independent. If a server fails, there is always an equivalent redundant OS server. The servers supervise each other during the runtime and synchronize the project archives if necessary.

The configuration is carried out via the ES.

Hardware configuration


Figure 5-1



Copyright © Siemens AG 2013 All rights reserved

PCS 7 configuration

Figure 5-2



5.2 Required Hardware and Software Licenses

Hardware

The following hardware is recommended for this configuration and can be ordered via the Siemens mall. Your selected operating system and the system software SIMATIC PCS 7 is then preinstalled accordingly.

Table 5-1

Station	Product information	Operating system	Plantbus transition
ES	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows 7	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows 7	CP 1623
2 x OS Single Station	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows 7	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows 7	CP 1623

Software licenses

In the following, the different software/license packages required for this configuration selection have been listed.

In the selected configuration as a redundant stand-alone system, the number of the POs is restricted to no more than 5000.

Table 5-2

Component	Software/license packages
ES	<ul style="list-style-type: none"> • SIMATIC PCS 7 AS/OS Engineering Software V8.0 (PO unlimited) • SIMATIC PCS 7 AS Runtime License (max. 2000 POs)
OS Single Station Redundant	<ul style="list-style-type: none"> • SIMATIC PCS 7 OS Software Single Station Redundancy V8.0 (single license for 2 installations) • 2 x SIMATIC PCS 7 OS Runtime License (max. 2000 POs)

5.3 Step-by-step Configuration

NOTE

The following instruction was generated on the basis of Windows 7 and PCS 7 V8.0 SP1.

For the plantbus transitions, CP1623 is used as an example. A clock synchronization is activated.

The PC stations in the test setup are called:

- ES: ES60
- OS- Server: SV60A
- OS-Server Standby: SV60B

5.3.1 ES Configuration

Generating the multiproject

As a basis for the following instruction, all PC stations must be physically networked according to Figure 5-1 (S.75). Furthermore, a multiproject must have been created on the ES in which the AS has already been configured regarding hardware and software.

Then you can start with the following CPU and CP settings.

AS settings

Evaluation of the process data requires all components of the process control system to work with an identical clock, so that messages can be allocated in the correct temporal sequence.



Below, a path is described where the redundant OS single stations define the master time.

NOTE

Further options of clock synchronization are described in detail in the following manuals:

- [SIMATIC Process Control System PCS 7 Operator Station \(V8.0\)](#)
- [SIMATIC Process Control System PCS 7 Time synchronization \(V8.0\)](#)

Table 5-3




Step	Activity	Screenshot
1.	<p>Open the HW Config of the AS. Select the CPU and choose “Object Properties...” from the context menu.</p>	 <p>The screenshot shows a hardware configuration window titled 'UR2ALU-H'. A tree view on the left lists components: 1 PS 407 10A, 3 CPU 417-4 H (selected), X2 DP, X1 MPL, IF1 H-Sy, IF2 H-Sy, 5 CP, X1 PN-A, X1 P1 R Port, X1 P2 R Port, 6 CP, X1 PN-A, X1 P1 R Port. A context menu is open over the CPU 417-4 H component, listing options such as Copy, Paste, Replace Object..., Add Master System, Disconnect Master System, Master System Isochronous Mode, Insert PROFINET IO System, Disconnect PROFINET IO System, PROFINET IO Domain Management..., PROFINET IO Topology..., PROFINET IO Isochronous mode, Specify Module..., Delete, Go To, Filter Assigned Modules, Monitor/Modify, Edit Symbols..., Object Properties... (highlighted), Open Object With..., Change Access, Assign Asset ID..., Product Support Information, FAQs, Find Manual, and Start Device Tool.</p>
2.	<p>Go to the “Diagnostics/Clock” tab. In the section under “Clock” set “As slave” for the AS under “Synchronization Type”. Confirm the setting with “OK”.</p>	 <p>The screenshot shows the 'Properties - CPU 417-4 - (R0/S4)' dialog box with the 'Diagnostics/Clock' tab selected. Under the 'System Diagnostics' section, 'Report cause of STOP' is checked. Under the 'Clock' section, 'Synchronization Type' is set to 'As slave' and 'Time Interval' is set to 'None'. The 'Correction factor' is set to 0 ms. Buttons for 'OK', 'Cancel', and 'Help' are visible at the bottom.</p>




Step	Activity	Screenshot
3.	Open the context menu of the CP and select "Object Properties...".	
4.	Go to the "Time-of-Day Synchronization" tab. Activate the option "Activate SIMATIC time-of-day synchronization". Confirm the setting with "OK".	
5.	Save and compile the configuration with "Station > Save and Compile". Close the HW Config.	

Generating the ES PC station

In order to take the OS project on the ES into operation, we generate a PC station for the ES with WinCC application.




Table 5-4

Step	Activity	Screenshot
<p>1.</p>	<p>In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”.</p> <p>Change the name of the PC station so that it corresponds to the name of the local computer in the network.</p>	 <p>The screenshot shows the SIMATIC Manager interface in Component view. A context menu is open over the project tree, with 'Insert New Object' selected. A sub-menu is displayed, showing 'SIMATIC PC Station' as the selected option. Other options include SIMATIC 400 Station, SIMATIC 300 Station, SIMATIC H Station, Other Station, SIMATIC S5, PG/PC, MPI, PROFIBUS, Industrial Ethernet, PTP, Foundation Fieldbus, S7 Program, Preconfigured Station..., OS, OS (Client), Shared Declarations, and Project Documentation.</p>
<p>2.</p>	<p>Open the HW Config of the PC station of the ES with the context menu.</p>	 <p>The screenshot shows the SIMATIC Manager interface. The context menu is now open over the newly created PC station object in the project tree. The 'Rename' option (F2) is highlighted, indicating the next step in the configuration process.</p>
<p>3.</p>	<p>From the object catalog (“View > Catalog”), add a “WinCC Application” and a network card of the type “CP1623”.</p>	 <p>The screenshot shows the HW Config window for the PC station. The hardware rack is populated with a 'WinCC Appl.' in slot 1 and a 'CP 1623' network card in slot 2. Slots 3 through 12 are currently empty.</p>




Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New...”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP and select “Object Properties...”.</p>	
6.	<p>Select the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via menu item “Station > Save and Compile”.</p> <p>Close the HW Config.</p>	
8. optional	<p>In the SIMATIC Manager, delete the OS project of the PC station of the ES as it is not required in our example.</p>	

Generating the master OS PC station

Table 5-5




Step	Activity	Screenshot
1.	In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”. You can choose its name freely.	 <p>The screenshot shows the SIMATIC Manager interface in 'Component view'. A context menu is open over the project tree, with 'Insert New Object' selected. A sub-menu is displayed, showing 'SIMATIC PC Station' as the selected option. Other options include SIMATIC 400 Station, SIMATIC 300 Station, SIMATIC H Station, Other Station, SIMATIC S5, PG/PC, MPI, PROFIBUS, Industrial Ethernet, PTP, Foundation Fieldbus, S7 Program, Preconfigured Station..., OS, OS (Client), Shared Declarations, and Project Documentation.</p>
2.	Open the HW Config of the PC station of the standby OS with the context menu.	 <p>The screenshot shows the SIMATIC Manager interface with the 'Configuration' view open. A context menu is open over the hardware configuration tree, with 'Configuration' selected. A sub-menu is displayed, showing 'CP 16' as the selected option. Other options include Open Object, Cut, Copy, Paste, Delete, and Rename.</p>
3.	From the object catalog (“View > Catalog”), add a “WinCC Application” and a network card of the type “CP1623”.	 <p>The screenshot shows the WinCC Application object catalog. The 'WinCC Appl.' object is selected in the first row, and the 'CP 1623' object is selected in the second row. The catalog lists 12 rows of objects.</p>




Copyright © Siemens AG 2013 All rights reserved

Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New...”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP and select “Object Properties...”.</p>	
6.	<p>Select the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via menu item “Station > Save and Compile...”.</p> <p>Close the HW Config.</p>	

Generating the standby OS PC station

Table 5-6



Step	Activity	Screenshot
1.	In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”. You can choose its name freely.	 <p>The screenshot shows the SIMATIC Manager interface in Component view. A context menu is open over the project tree, with 'Insert New Object' selected. A sub-menu is displayed, showing 'SIMATIC PC Station' as the selected option. Other options include SIMATIC 400 Station, SIMATIC 300 Station, SIMATIC H Station, Other Station, SIMATIC S5 PG/PC, MPI, PROFIBUS, Industrial Ethernet, PTP, Foundation Fieldbus, S7 Program, Preconfigured Station..., OS, OS (Client), Shared Declarations, and Project Documentation.</p>
2.	Open the HW Config of the PC station of the standby OS with the context menu.	 <p>The screenshot shows the SIMATIC Manager interface. A context menu is open over the project tree, with 'Open Object' selected. The menu also shows 'Cut', 'Copy', 'Paste', 'Delete', and 'Rename' options.</p>
3.	From the object catalog (“View > Catalog”), add a “WinCC Application (stby)” and a network card of the type “CP1623”.	 <p>The screenshot shows the HW Config window for a PC station. The hardware rack is populated with a WinCC Appl. in slot 1 and a CP 1623 network card in slot 2. Slots 3 through 12 are currently empty.</p>




Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New...”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP and select “Object Properties...”.</p>	
6.	<p>Select the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via menu item “Station > Save and Compile...”.</p> <p>Close the HW Config.</p>	

Configuring all PC stations

The function “Configure PC station” transfers the project configuration to one or more PLCs. First configure the local components configurator of the ES and then the OS connected to the plantbus.

Table 5-7

Step	Activity	Screenshot
1.	Configure the component configurator of the ES. Select the PC station of the ES and choose “PLC > Configure...” from the context menu.	
2.	Under “Accessible computers”, choose the PC which is provided for configuration. NOTE If you chose the option “Computer name identical to the PC station name” in the component view “Object Properties” for the PC station, the component configurator directly displays the target computer to be configured. With the button “Display”, you can have the current configuration of the PC station displayed. Hit the “Configure...” button.	



Step	Activity	Screenshot
3.	<p>In the displayed window you see how the PC station is configured. Confirm this setting with "OK".</p>	
4.	<p>Acknowledge the information dialog with "OK".</p>	
5.	<p>Finally, you receive the following message in the bottom window: "Transfer completed successfully." Close the configuration dialog box.</p>	
6.	<p>Please configure the component configurator of the master and the standby OS analog to steps 1 to 5.</p>	

Configuration and download of the AS/OS communication




In the following, the connections between the PC stations and the AS in NetPro are configured and downloaded into the individual stations.

NOTE For station granular configuration, the subnets of the individual subprojects must be joined beforehand.

Table 5-8

Step	Activity	Screenshot
1.	Open NetPro. Select the WinCC application of the ES and open the context menu. Choose "Insert New Connection".	
2.	In the "Connection Partner" window, select the CPU of the AS. Ensure that in the "Connection" field a "S7 connection" has been selected. In this example, a fault-tolerant S7 connection is configured due to the AS configuration. Confirm the setting with "OK".	




Copyright © Siemens AG 2013 All rights reserved



Step	Activity	Screenshot
3.	<p>In the “General” tab, in “Connection identification” change the “Local ID” into a meaningful name, like AS60.</p> <p>Confirm the settings with “OK”.</p>	
4.	<p>Repeat steps 1 to 3 for connecting the master OS and the standby OS to the AS. It is important that the connection of master OS, standby OS and ES to the AS have identical names.</p> <p>Then, save and compile the configuration with the menu item “Network > Save and compile...”.</p> <p>Choose the option “Compile and check everything” and confirm with “OK”.</p>	
5.	<p>Mark the ES and then, over the menu item load “PLC > Download to Current Project > Selected Stations”.</p> <p>Download the AS, master OS, and standby OS in the same way.</p> <p>Then close NetPro.</p>	

Master/standby settings on the ES

Here you make the master/standby assignment and select the download paths.

Table 5-9

Step	Activity	Screenshot
1.	<p>In the SIMATIC Manager, open the properties dialog of the master OS. Switch to the “Target OS and Standby OS Computer” tab. In the “Standby-OS” drop-down menu, select the Standby OS. Checkmark the “Create/update archive tags” box and deselected “Transfer to central archive server”. Press the “Search” button.</p>	
2.	<p>Navigate by the drop down menu to the enable project folder of the OS server (see 6.3.1 Preparatory Steps). Hit the “Save” button.</p>	
3.	<p>Check the path in the box “Path to the Target OS Computer”. Confirm this with “OK”. Also confirm the message box that appears with the “OK” button.</p>	
4.	<p>Open the Properties dialog of the standby OS. Switch to the “Target OS and Master OS Computers” tab. Verify that the master OS has also been entered in “Master OS”. Hit the “Search...” button to choose the storage path of the OS data.</p>	

Step	Activity	Screenshot
5.	Navigate by the drop down menu to the enable project folder of the OS standby server (see 6.3.1 Preparatory Steps). Hit the "Save" button.	
6.	Check the path in the box "Path to the Target OS Computer" and confirm this with "OK". Confirm the message that appears with the "OK" button.	

Compile and download the user program

Compile the S7 program and download it into the AS.

Compiling the OS project


Compile the OS project of the master OS in the SIMATIC Manager. Look out for the correct OS assignment to the server in Plant View.





5.3.2 OS Configuration


OS configuration on the Engineering Station

Conversion from multi to single place systems is made on the ES, as well as settings for redundancy and clock synchronization.

Table 5-10

Step	Activity	Screenshot
1.	<p>Open the OS project of the master OS on the ES computer.</p> <p>In the opened WinCC Explorer, open the OS project and select "Properties" in the context menu.</p>	 <p>The screenshot shows the WinCC Explorer interface. The title bar reads 'WinCC Explorer - D:\Projects\6_MP_MP_'. The menu bar includes 'File', 'Edit', 'View', 'Tools', and 'Help'. The main workspace displays a tree view of project components. The 'OS_Master' component is selected, and a context menu is open over it. The menu items are: 'Find...', 'Properties', 'Structure tag', 'Graphics Designer', 'Alarm Logging', 'Tag Logging', 'Report Designer', 'Global Script', 'Text Library', 'Text Distributor', 'User Administrator', 'Cross-Reference', 'Server data', 'Redundancy', 'User Archive', 'Time synchronization', 'Horn', 'Picture Tree Manager', 'Lifebeat Monitoring', 'OS Project Editor', 'Component List Editor', 'SFC', and 'Web Navigator'. The 'Properties' option is highlighted in blue.</p>



Step	Activity	Screenshot
2.	<p>In the “General” tab under “type:”, select “Single-user project”.</p> <p>Confirm the selection and the message that appears with the “OK” button.</p>	 
3.	<p>Prevent deleting the startup list by pressing the “No” button.</p>	
4.	<p>Open the editor “Redundancy” with the context menu.</p> <p>Activate the option box “Default Master”.</p> <p>Under “Redundanter Partner Sever:” the standby OS must be entered.</p> <p>Check whether your desired checkboxes are activated at “Optional Settings”.</p> <p>If you do not wish to operate the RS 232 redundancy cable at the COM1 interface, then these settings must later be performed on the OS itself (see section “OS configuration on the Operator Station”).</p> <p>Confirm the settings with “OK”.</p>	


Step	Activity	Screenshot
5.	<p>Open the editor "Time synchronization" with the context menu.</p> <p>Here, activate the checkbox "Synchronization via System Bus (Master, Slave)".</p> <p>In "Access point 1", select "CP1623(ISO)" and activate the "Master" radio button.</p> <p>Activate the option box "Display symbolic name of the access point".</p> <p>Confirm the settings with "OK".</p> <p>NOTE If the ES server does not have a CP1623, the settings for the clock synchronization cannot be executed here. The clock synchronization settings must, in this case, be executed on both single stations itself after downloading the OS project.</p>	
6.	Close the OS project.	

Downloading OS project to the OS computers

After the redundancy and clock synchronization have been configured on the ES side, the OS project can be downloaded to the master and standby OS.

Table 5-11

Step	Activity	Screenshot
1.	In the SIMATIC Manager, select the master OS and select "PLC > Download" from the context menu.	 <p>The screenshot shows the SIMATIC Manager interface. The project tree on the left includes '6_MP_MP_reorg' and its sub-objects. The 'OS_Master' object is selected, and a context menu is open. The 'PLC' option is highlighted, and its sub-menu is also open, showing the 'Download' option with the keyboard shortcut 'Ctrl+L'.</p>
2.	Downloading the OS project for the first time requires a complete download. Start the download with "OK".	 <p>The screenshot shows the 'Download OS' dialog box. The 'Target system' is set to '\\SV60A\Projects\OS_Master\OS_Master.mcp'. Under the 'Scope' section, 'The entire WinCC project' is selected. There is an unchecked checkbox for 'Start compilation before downloading'. A message box states: 'The entire WinCC project will be transferred to the runtime OS.' At the bottom, there are 'OK', 'Cancel', and 'Help' buttons.</p>

Step	Activity	Screenshot
3.	After the successful download, the OS project is located on the master OS in the intended folder. Confirm this with "OK".	
4.	Repeat steps 1 to 3 to download the OS project to the standby OS.	



Configuration of the Operator Station

If the engineering station has no CP1623 as opposed to the OS, or the RS 232 redundancy cable is not connected at COM1 there, the following step-by-step instructions must be performed. Otherwise, we generally advise you to check the project settings after the project download onto the target systems.


NOTE

Normally, all configuration works are executed on the ES for the purpose of consistent data management, so that no WinCC engineering licenses are required on the OS. Nevertheless, a license free time window of one hour is available after each opening of the WinCC Explorer for WinCC configuration works.

Table 5-12

Step	Activity	Screenshot
1.	Open the OS project on the master OS.	
2.	<p>Open the editor “Redundancy” with the context menu.</p> <p>Check the name of the master OS in the field “Server”.</p> <p>The “Default Master” checkbox must be activated.</p> <p>Also check whether, under “Redundant Partner Server:” the name of the standby OS has been entered correctly.</p> <p>Check whether your desired checkboxes are activated at “Optional Settings”.</p> <p>If you are operating the RS 232 redundancy cable at a location different to the COM1 interface, you have to set the appropriate interface at “Serial connection to redundant partner:”.</p> <p>Confirm the settings with “OK”.</p>	
3.	<p>Open the editor “Time synchronization” with the context menu.</p> <p>Here, activate the checkbox “Synchronization via System Bus (Master, Slave)”.</p> <p>In “Access point 1”, check or select “CP1623(ISO)” and press the “Master” radio button.</p> <p>Confirm the settings always with “OK”.</p>	
4.	If you made any changes in the WinCC Explorer project, close the OS project and open it again to activate the settings.	

Copyright © Siemens AG 2013 All rights reserved

Step	Activity	Screenshot
5.	<p>Repeat steps 1 to 4 on the standby OS with the following modifications for step 2 (redundancy):</p> <ul style="list-style-type: none"> The “Default Master” checkbox must be deactivated. Also check, whether under “Redundant Partner Server:” the name of the master OS has been entered correctly. 	

5.3.3 Activating Runtime

Successively activate the OS project on the master OS as well as on the standby OS. It is recommended to wait with activating the second Runtime until the start process of the first one is completed entirely.

Regarding the redundancy, the online synchronization is active immediately. The mutual archive update, on the other hand, takes approx. 10-15 min.

6 ES/OS-Master and OS-Standby

6.1 Configuration Description

For this configuration with two redundant OS single-user systems one of both stations is simultaneously used as ES, which saves a separate third station.

The following two criteria must be followed here, which is why generally a configuration with separate ES is advised (see chapter 5 “ES, OS Master and OS Standby”):

Comparatively low saving potential

The saving potential is reduced since PCS 7 V8.0, as the OS Runtime license is no longer contained in the ES license. The savings are therefore restricted to the PC (Hardware and Windows license).

Particular features for programming

The configuration deviates from the PCS 7 engineering standard and represents a sort of a workaround.


The PCS 7 standard tools for the redundant OS stations “WinCC application” and “WinCC Application Standby” cannot be used, since a delta download would not be possible here during runtime. The mechanisms where both systems need to be in runtime, and Runtime must be terminated on the ES for the download, mutually block each other.

For this reason, we now configure an OS application, open it on both stations, and configure the mutual redundancy respectively local in WinCC. For downloading to the OS Single Station, the Runtime and the OS on the ES must be closed,

NOTICE This configuration has been tested with a PCS 7 basic installation, including Web Option. For the function in conjunction with additional option packages, a statement cannot be made.


Hardware configuration

Figure 6-1



PCS 7 configuration

Figure 6-2



Particularities / restrictions

Due to the nontypical PCS 7 configuration with only one OS there are differences in the system behavior which must be considered:

- The first activated OS takes on the master role.
- For the complete download, Runtime must be deactivated for both computers, and the WinCC Explorer must be closed. During this time, neither operator actions nor archiving is possible.
- For a delta-download, Runtime on the ES must be closed again for compiling the OS. It can then be re-activated for testing the modified OS functions. For the downloading, Runtime must be terminated and the WinCC project must be closed.

The following restrictions result:

- No operator actions can take place at the ES computer at that time.

NOTICE

If Runtime remains active on the ES during the OS compilation, it might happen - depending on the changes made - that a subsequent delta-download is carried out incompletely and results in errors. Afterwards, only a complete download will be possible.

- Runtime being active on the ES computer results in the runtime archive being stored under the multiproject path. Therefore, they are also included into the ZIP file during archiving and cause increased storage space as well as archiving times.

Workaround:

- Deactivate Runtime on the ES computer.
- Reset archive in the OS project on the ES computer and close the entire PCS 7 project.

After archiving and reactivating Runtime, the archives are updated again. Please note that more time will be needed for checking.

6.2 Required Hardware and Software Licenses

Hardware

The following hardware is recommended for this configuration and can be ordered via the Siemens mall. Your selected operating system and the system software SIMATIC PCS 7 is then preinstalled accordingly.

Table 6-1

Components	Product information	Operating system	Plantbus transition
ES/OS	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows 7	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows 7	CP 1623
OS Single Station	SIMATIC PCS 7 ES/OS IPC547D BCE	Windows 7	RJ45 network card
	SIMATIC PCS 7 ES/OS IPC547D IE	Windows 7	CP 1623

Software licenses

In the following, the different software/license packages required for this configuration selection have been listed.

Table 6-2

Components	Software/license packages
ES	<ul style="list-style-type: none"> SIMATIC PCS 7 AS/OS Engineering Software V8.0 (PO unlimited) SIMATIC PCS 7 AS Runtime License (max. 2000 POs)
OS Single Station Redundant	<ul style="list-style-type: none"> SIMATIC PCS 7 OS Software Single Station Redundancy V8.0 (single license for 2 installations) 2 x SIMATIC PCS 7 OS Runtime License (max. 2000 POs)

6.3 Step-by-step Configuration

NOTE

The following instruction was generated on the basis of Windows 7 and PCS 7 V8.0 SP1.

For the plantbus transitions, CP1623 is used as an example. Additionally, the clock synchronization is activated.

The PC stations in the test setup are called:

- ES/OS-Master: ES60
- OS-Stanby: SV60A

6.3.1 ES Configuration

Generating the multiproject

As a basis for the following instruction, all PC stations must be physically networked according to Figure 6-1. Furthermore, a multiproject must have been created on the ES in which the AS has already been configured regarding hardware and software.

Then you can start with the following CPU and CP settings.

AS settings for the clock synchronization

Evaluation of the process data requires all components of the process control system to work with an identical clock, so that messages can be allocated in the correct temporal sequence.



Below, a path is described where the redundant OS single stations define the master time.



NOTE

Further options of clock synchronization are described in detail in the following manuals:

- [SIMATIC Process Control System PCS 7 Operator Station \(V8.0\)](#)
- [SIMATIC Process Control System PCS 7 Time synchronization \(V8.0\)](#)

Table 6-3




Step	Activity	Screenshot
1.	<p>Open the HW Config of the AS. Select the CPU and choose “Object Properties...” from the context menu.</p>	 <p>The screenshot shows the HW Config interface for a rack (UR2ALU-H) containing a PS 407 10A and a CPU 417-4 H. A context menu is open over the CPU, listing various actions. The 'Object Properties...' option is highlighted in blue, with the keyboard shortcut 'Alt+Return' displayed next to it. Other options include Copy, Paste, Replace Object..., Add Master System, Disconnect Master System, Master System Isochronous Mode, Insert PROFINET IO System, Disconnect PROFINET IO System, PROFINET IO Domain Management..., PROFINET IO Topology..., PROFINET IO Isochronous mode, Specify Module..., Delete, Go To, Filter: Assigned Modules, Monitor/Modify, Edit Symbols..., Open Object With..., Change Access, Assign Asset ID..., Product Support Information, FAQs, Find Manual, and Start: Device Tool.</p>
2.	<p>Go to the “Diagnostics/Clock” tab. In the section under “Clock”, set “As slave” for the AS under “Synchronization Mode”. Confirm this setting with “OK”.</p>	 <p>The screenshot shows the 'Properties - CPU 417-4 - (R0/54)' dialog box. The 'Diagnostics/Clock' tab is active. Under the 'Clock' section, the 'Synchronization' settings are visible. The 'In the ELC:' dropdown is set to 'As slave'. The 'On MPI:' and 'On ME:' dropdowns are both set to 'None'. The 'Time Interval' dropdowns are also set to 'None'. The 'Correction factor' is set to '0 ms'. The 'System Diagnostics' section has 'Report cause of STOP' checked. The 'Number of messages in the diagnostic buffer' is set to '3000'. The 'OK' button is highlighted.</p>




Step	Activity	Screenshot
3.	Open the context menu of the CP and select "Object Properties...".	
4.	Go to the "Time-of-Day Synchronization" tab. Activate the option "Activate SIMATIC time-of-day synchronization". Confirm the setting with "OK".	
5.	Save and compile via menu item "Station > Save and Compile". Close the HW Config.	

Generating the ES PC station

In order to take the OS project on the ES into operation, we generate a PC station for the ES with WinCC application.




Table 6-4




Step	Activity	Screenshot
1.	<p>In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”.</p> <p>Change the name of the PC station so that it corresponds to the name of the local computer in the network.</p>	
2.	<p>Open the HW Config of the PC station of the ES with the context menu.</p>	
3.	<p>From the object catalog (“View > Catalog”), add a “WinCC Application” and a network card of the type “CP1623”.</p>	





Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New...”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP 1623 and select “Object Properties...”.</p>	
6.	<p>Select the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via the menu item “Station > Save and Compile...”.</p> <p>Close the HW Config.</p>	
8.	<p>In the SIMATIC Manager, delete the OS project of the PC station of the ES as it is not required in our example.</p>	

Generating the standby OS PC station

Table 6-5

Step	Activity	Screenshot
1.	In the “Component view”, open the context menu of the project and insert a new PC station via “Insert New Object > SIMATIC PC Station”. You can choose its name freely.	
2.	Open the HW Config of the PC station of the standby OS with the context menu.	
3.	From the object catalog (“View > Catalog”), add a “WinCC Application” (no WinCC Application Stby!) and a network card of the type “CP1623”.	



Step	Activity	Screenshot
4.	<p>Under “Subnet”, select the Plant Bus or create it with the button “New...”.</p> <p>Assign the respective MAC address to the CP 1623.</p> <p>Deactivate the option “IP protocol is being used”.</p> <p>Confirm the settings with “OK”.</p>	
5.	<p>Open the context menu of the CP 1623 and select “Object Properties...”.</p>	
6.	<p>Select the “Options” tab and checkmark the “Time of day” box.</p> <p>Confirm the setting with “OK”.</p>	
7.	<p>Save and compile via menu item “Station > Save and Compile...”.</p> <p>Close the HW Config.</p>	




Step	Activity	Screenshot
8.	<p>In the SIMATIC Manager, open the properties dialog of the OS project. Switch to the “Target OS and Standby OS Computer” tab. Checkmark the “Create/update archive tags” box and deselected “Transfer to central archive server”. Press the “Search” button.</p>	
9.	<p>Navigate by the drop down menu to the enable project folder of the OS server (see 5.3.1 Preparatory Steps). Hit the “Save” button.</p>	
10.	<p>Check the path in the box “Path to the Target OS Computerr”. Confirm this with “OK”.</p>	
11.	<p>Acknowledge the information dialog with the “Yes” button.</p>	

Configuring the PC stations

The function “Configure PC station” transfers the project configuration to one or more PLCs. First configure the local components configurator of the ES and then the all the other PC Stations connected with the plantbus.

Table 6-6

Step	Activity	Screenshot
1.	<p>Configure the component configurator of the ES. Select the PC station of the ES and choose “PLC > Configure...” from the context menu.</p>	
2.	<p>Under “Accessible computers”, choose the PC which is provided for configuration.</p> <p>NOTE If you chose the option “Computer name identical to the PC station name” in the component view “Object Properties” for the PC station, the component configurator directly displays the target computer to be configured.</p> <p>With “Display”, you can have the current configuration of the PC station displayed. Hit the “Configure...” button.</p>	



Step	Activity	Screenshot
3.	In the displayed window you see how the PC station is configured. Confirm this setting with "OK".	
4.	Acknowledge the information dialog with "OK".	
5.	Finally, you receive the following message in the bottom window: "Transfer completed successfully." Close the configuration dialog box.	
6.	Please configure the component configurator of the OS server analog to steps 1 to 5.	




Configuration and download of the AS/OS communication

In the following, the connections between the PC stations and the AS in NetPro are configured and downloaded into the individual stations.

NOTE For station granular configuration, the subnets of the individual subprojects must be joined beforehand.

Table 6-7

Step	Activity	Screenshot
1.	<p>Open NetPro. Select the WinCC application of the ES and open the context menu. Choose "Insert New Connection".</p>	 <p>The screenshot shows the NetPro interface with a context menu open over a WinCC application icon. The menu options include 'Insert New Connection', 'Highlight', 'Download to current project', 'Rearrange', and 'Object Properties...'. Below the menu, a network diagram shows connections between ES60 and SV60A stations to an AS60 station.</p>
2.	<p>In the "Connection Partner" window, select the CPU of the AS. Make sure that in the "Connection" field a "S7 connection" has been selected. In this example, a fault-tolerant S7 connection is configured due to the AS configuration. Confirm the setting with "OK".</p>	 <p>The screenshot shows the 'Insert New Connection' dialog box. The 'Connection Partner' tree is expanded to show 'CPU 417-4 H/CPU 417-4 H(1)'. The 'Project' field is set to '5_MP_Prij', 'Station' to 'AS60', and 'Module' to 'CPU 417-4 H/CPU 417-4 H(1)'. The 'Connection' type is set to 'S7 connection fault-tolerant'. The 'Display properties before inserting' checkbox is checked. Buttons for 'OK', 'Apply', 'Cancel', and 'Help' are visible at the bottom.</p>

Step	Activity	Screenshot
3.	<p>In the “General” tab, in “Connection identification” change the “Local ID” into a meaningful name, like AS60.</p> <p>Confirm the settings with “OK”.</p>	
4.	<p>Create the connection between the standby OS and the AS in the same way, by repeating steps 1 to 3.</p> <p>It is important that the connection has the same name as the connection of the ES to the AS.</p> <p>Then, save and compile the configuration with the menu item “Network > Save and compile...”.</p> <p>Choose the option “Compile and check everything” and confirm with “OK”.</p>	
5.	<p>Mark the ES and then download the connections via the context menu “Download to Current Project > Selected Stations”.</p> <p>Download the standby OS and the AS in the same way.</p> <p>Then close NetPro.</p>	

Compile and download the user program

Compile the S7 program and download it into the AS.

Compiling the OS project

Compile the OS project in the SIMATIC Manager.

Look out for the correct OS assignment to the server in Plant View.


6.3.2 OS Configuration





OS configuration on the Engineering Station



Conversion from multi-place to single-place systems is made on the ES, as well as settings for redundancy and clock synchronization.




NOTE For this particular configuration, it is necessary to complete the redundancy setting in the WinCC Explorer of the standby OS after the entire download.

Table 6-8

Step	Activity	Screenshot
1.	<p>Open the OS-Standby project on the ES computer.</p> <p>In the opened WinCC Explorer, open the OS project and select "Properties" in the context menu.</p>	 <p>The screenshot shows the WinCC Explorer interface. The title bar reads 'WinCC Explorer - D:\Projects\color_gs\colo_Prj\wincp'. The menu bar includes 'File', 'Edit', 'View', 'Tools', and 'Help'. The main workspace displays a tree view of project components. The 'OS_stbv' project is selected, and a context menu is open over it, showing options like 'Find...', 'Properties', 'Structure tag', 'Graphics Designer', 'Alarm Logging', 'Tag Logging', 'Report Designer', 'Global Script', 'Text Library', 'Text Distributor', 'User Administrator', 'Cross-Reference', 'Server data', 'Redundancy', 'User Archive', 'Time synchronization', 'Horn', 'Picture Tree Manager', 'Lifebeat Monitoring', 'OS Project Editor', 'Component List Editor', 'Faceplate Designer', 'SFC', and 'Web Navigator'. The 'Properties' option is highlighted.</p>

Step	Activity	Screenshot
2.	In the “General” tab, under “type:”, select “Single-user project”.	 <p>The screenshot shows the 'Project properties' dialog box with the 'General' tab selected. Under 'General Data of the Current Project', the 'Type' dropdown menu is set to 'Single-User Project'. Other fields include Creator (WinCC-Project-Manager), Creation Date (9/5/2012 10:49:49 AM), Changed By (WinCC-Project-Manager), Last Change (9/10/2012 4:10:52 PM), Version, GUID (CC_OS_2_12_09_05_08_49_47), and a Comment field.</p>
3.	Confirm the selection and the message that appears with the “OK” button.	 <p>The screenshot shows a warning message dialog box with a question mark icon. The text reads: 'A change from a multi-user to a single-user or WinCC client project will delete all configured client computers from the computer list. Click on <OK> to perform this change, or on <CANCEL> to keep the multi-user project.' There are 'OK' and 'Cancel' buttons at the bottom.</p>
4.	Via the “Options” tab, checkmark the OS project option “Allow activation on ES”. With this setting Runtime can be simulated on the ES. Press the “OK” button.	 <p>The screenshot shows the 'Project properties' dialog box with the 'Options' tab selected. Under 'Additional project options', the 'Allow activation on ES' checkbox is checked. Other options include 'Help available in Runtime' and 'Color conversion when printing messages'. A text box below states: 'This option disables the project activation interlock on the ES.' There are 'OK' and 'Cancel' buttons at the bottom.</p>
5.	Prevent deleting the startup list by pressing the “No” button. Confirm the message that appears with the “OK” button.	 <p>The screenshot shows a confirmation dialog box with a question mark icon. The text reads: 'The project type was changed. Do you want to delete the startup list?' There are 'Yes' and 'No' buttons at the bottom.</p>




Step	Activity	Screenshot
6.	<p>Open the editor “Redundancy” with the context menu. Activate the option box “Activate Redundancy”.</p> <p>Activate the option box “Default Master”. If necessary, adjust the redundancy properties in “Optional Settings” to your requirements.</p> <p>If you do not wish to operate the RS 232 redundancy cable at the COM1 interface, then these settings must later be performed on the OS itself (see section “OS configuration on the OS”).</p>	
7.	<p>To complete the redundancy settings for the ES, the partner server must be selected.</p> <p>Select the standby OS as redundant partner via the “Browse...” button out of the PC network.</p> <p>Confirm the settings with “OK”.</p>	

Step	Activity	Screenshot
8.	Control the redundancy settings before you confirm via “OK” button.	
9.	Confirm the message that appears with the “OK” button.	
10.	<p>Open the “Time Synchronization” editor.</p> <p>Here, activate the checkbox “Synchronization via System Bus (Master, Slave)”.</p> <p>In “Access point 1”, select “CP1623(ISO)” and activate the “Master” radio button.</p> <p>Confirm the settings with “OK”.</p> <p>NOTE If the ES server does not have a CP 1623, the settings for the clock synchronization cannot be executed here. The clock synchronization settings must, in this case, be executed on the standby OS itself after downloading the OS project.</p>	
11.	Close the OS project.	

Loading OS project to the standby OS

After the redundancy and clock synchronization have been configured on the ES side, and the OS project has been closed, download the OS project onto the standby OS.

Table 6-9

Step	Activity	Screenshot
1.	In the SIMATIC Manager, select the standby OS and select "PLC > Download" from the context menu.	
2.	Downloading the OS project for the first time requires a complete download. Start the download with "OK".	
3.	After the successful download, the OS project is located on the standby OS in the intended folder. Confirm this with "OK".	

OS configuration on the standby OS


For this special configuration, it is necessary to make the redundancy settings before the download.




If the engineering station has no CP 1623 as opposed to the OS, or the RS 232 redundancy cable is not connected at COM1 there, the following step-by-step instructions must be performed. Otherwise, we generally advise you to check those after the project download onto the target system.

NOTE

Normally, all configuration works are executed on the ES for the purpose of consistent data management, so that no WinCC engineering licenses are required on the OS. Nevertheless, a license free time window of two hours is available after each opening of the WinCC Explorer for WinCC configuration works.

Table 6-10

Step	Activity	Screenshot
1.	Open the WinCC Explorer on the standby OS.	
2.	<p>Open the editor "Redundancy" with the context menu.</p> <p>Select the standby OS as redundant partner via the "Browse..." button out of the PC network.</p> <p>Confirm the settings with "OK".</p>	

Step	Activity	Screenshot
	<p>Here, uncheck the “Default Master” checkbox.</p> <p>Select the ES computer as redundant partner via the “Browse...” button.</p> <p>Check whether your desired checkboxes are activated at “Optional Settings”.</p> <p>Confirm the settings with “OK”.</p>	
	<p>Confirm the information dialog with the “OK” button.</p>	
<p>3.</p>	<p>Open the editor “Time synchronization” with the context menu.</p> <p>Here, activate the checkbox “Synchronization via System Bus (Master, Slave)”.</p> <p>In “Access point 1”, check or select “CP1623(ISO)” and press the “Master” radio button.</p> <p>Confirm the settings always with “OK”.</p>	

Step	Activity	Screenshot
4.	If you made any changes in the WinCC Explorer project, close the OS project and open it again to activate the settings.	

6.3.3 Activating Runtime

Successively start the OS project on the ES as well as on the standby OS. It is recommended to wait with activating the second Runtime until the start process of the first one is completed entirely.

Regarding the redundancy, the online synchronization is active immediately. The mutual archive update, on the other hand, takes approx. 10-15 min.

6.3.4 Particularities at downloading of OS Project Modifications

Delta-download

For a delta-download, Runtime on the ES must be closed again for compiling the OS. It can then be re-activated for testing the modified OS functions.

NOTICE

If Runtime remains active on the ES during the OS compilation, it might happen - depending on the changes made - that a subsequent delta-download is carried out incompletely and results in errors. Afterwards, only a complete download will be possible.

For the downloading, Runtime must be terminated and the WinCC project must be closed.

The following restrictions result:

- No operator actions can take place at the ES computer at that time.

Complete download

For downloading the complete program, please note:

1. Runtime must be deactivated on both PC stations and the WinCC project must be closed.
2. Before Runtime is activated again on the standby OS, the redundancy settings must be made.
Repeat the steps from Table 6-10

7 Expansion by PCS 7 Web Option

Positioning

To control automated processes via the Internet/Intranet, SIMATIC PCS 7 offers control and monitoring options, the so called Web options.

This chapter describes the configuration of the Web Option on an ES/OS stand-alone system. The instruction can therefore be used as expansion for the following minimal configurations:

- ES/OS stand-alone system (chapter 3)
- Master ES/OS and Standby OS (chapter 5)

NOTE

In the following we configured exemplified the ES/OS stand-alone system as Web server for stand alone systems with Web Options. Analog is it possible to configure the partner-OS as Web server, without reservation of functionality for the Web clients.

If one of the redundant operator stations acts as Web server, the redundancy is not available for the Web clients. If this OS is in STOP mode, then Web clients have no connection to the process either.

Function

All relevant pictures and scripts are stored on the Web server, so that they can be displayed and run via a Web client.

At the same time the Web client accesses the stored process cell data on the Web server via a TCP/IP connection. The user interface looks like an OS standard client with overview, work and key area.

Among others, the following functions are available via the web:

- Control and monitoring functions that are also used on an OS client
- Message lists which can be called user-dependent just like on an OS client. Messages can be acknowledged user-dependent.
- Display of picture hierarchy according to plant hierarchy
- Group display function including “Loop-in-Alarm” function.
- Advanced status display

NOTE

You can find further information regarding PCS 7 Web Options in the manual:

- [SIMATIC Process Control System PCS 7 Web Option for OS \(V8.0\)](#)


7.1 Web Configurations

In our example, the configuration of the Web Option represents an extension of the hard- and software configurations of chapter 3 "ES/OS Stand-alone Systems" and chapter 5 "ES/OS-Master and OS-Standby".

ES/OS stand-alone system as OS Web server

To control and monitor the process in the Internet Explorer, the OS Web clients retrieve their data from the Web server via the Intranet/Internet.

Figure 7-1: Web Option Configuration in stand-alone system




ES/OS Master as OS Web server

To control and monitor the process in the Internet Explorer, the OS Web clients retrieve their data from the Web server via the Intranet/Internet.

Furthermore, the system process has a redundant design to offer the plant operation the greatest possible failure protection.

NOTICE The redundancy of the Operator Stations is not available for the Web clients. If the OS with the Web server option is in STOP, the Web clients have no process connection.

Figure 7-2: Web Option Configuration in redundant stand-alone system



7.2 Web-Specific Hardware and Software Requirements

Stand-alone system with Web server option

Tabelle 7-1

Component	Requirement
Operating system	<ul style="list-style-type: none"> Windows XP Professional SP3 (32Bit) Windows Server 2003 SP2 Standard Edition (32Bit) Windows Server 2003 R2 SP2 Standard Edition (32Bit) Windows 7 Ultimate SP1 (32Bit) Windows 7 Ultimate SP1 (64Bit) Windows Server 2008 SP2 Standard Edition (32Bit) Windows Server 2008 R2 SP1 Standard Edition (64 Bit) <p>You can find additional information on this in the document „SIMATIC Process Control System PCS 7 PCS 7 Readme V8.0 SP1“.</p>
Hardware	<ul style="list-style-type: none"> Windows XP Professional SP3 (32Bit) Windows Server 2003 SP2 Standard Edition (32Bit) Windows Server 2003 R2 SP2 Standard Edition (32Bit) Windows 7 Ultimate SP1 (32Bit) Windows 7 Ultimate SP1 (64Bit) Windows Server 2008 SP2 Standard Edition (32Bit) Windows Server 2008 R2 SP1 Standard Edition (64 Bit) <p>You can find information on this in the document „SIMATIC Process Control System PCS 7 PCS 7 Readme V8.0 SP1“.</p>
Software	<ul style="list-style-type: none"> Internet Explorer Internet Information Services (IIS)
Miscellaneous	Fast access (≥ 64 kbit/s) to Web client over Intranet/Internet or via TCP/IP connection

Web client

Tabelle 7-2

Component	Requirement
Operating system	You can find information on this in the document „SIMATIC Process Control System PCS 7 PCS 7 Readme V8.0 SP1“ .
Minimum hardware requirement	No PDAs, tablet PCs etc.
Software	Internet Explorer
Miscellaneous	Fast access (≥ 64 kbit/s) to Web server via Internet/Intranet or TCP/IP connection

NOTE

Choose the Internet Explorer Version according to the PCS 7 version. You can find further information in the following FAQ:

<http://support.automation.siemens.com/WW/view/en/2334224>

7.3 Maximal number of Web client accesses

The following numbers of simultaneous Web client accesses are tested and released:

Table 7-3

Operating system on the stand-alone system with Web server option	Maximal number of simultaneous Web accesses
Windows XP	2
Windows 7	3
Windows Server 2003	3
Windows Server 2008	3

7.4 Configuration of OS Web server

Configuration steps on the ES

- Publishing of pictures by means of Web View Publisher
- Configuring user rights, start screen and language of website in user administrator
- Loading and compiling of Web server

Publishing of OS data

Pictures and scripts which are supposed to run on the Web clients later are published on the OS Web server using the Web Publisher. Doing this, the following actions are carried out:

- Project data is compressed and stored
- Screen windows are transferred into web-enabled ActiveX components
- Scripts are converted so that they can be run on the web

Requirements

To be able to publish the Web server data the following prerequisites have to be fulfilled:

- The requirements mentioned in chapter 7.2 are met.
- The software package "PCS 7 Web server" is installed on the ES/OS stand alone system.
- PCS 7 project is readily configured
- OS has already been compiled
- Scripts which the Web clients access are available
- Process pictures do not have a double underscore (e.g. yy__xx.pdl)
- Variable name in plain text (inverted commas) in C scripts contain no spaces

NOTE





For a stand-alone system only one publishing process for the publishing of local data on the Web server is necessary.




Information regarding the issue of "Supported script normal functions" can be found in the manual:



- [SIMATIC Process Control System PCS 7 Web Option for OS \(V8.0\)](#)
(chapter „Web-Executable Functions for PCS 7 OS Web Option“)

7.4.1 Publishing of Project Data

Table 7-4

Step	Action	Note
1.	<p>Open the OS project of the OS Web server in WinCC Explorer.</p> <p>Select the command "Web View Publisher" via the context menu of the "Web Navigator" editor.</p> <p>The "WinCC Web Publishing Wizard – Introduction" dialog field opens up.</p> <p>Click the "Next" button.</p>	
2.	<p>The "WinCC Web Publishing Wizard – Select directories" dialog field opens up.</p> <p>Disable the option "Server Prefix" since you want to publish local data.</p> <p>Accept the preset target and source path. If you would like to change the respective path, click the button behind the shaded input fields. Navigate to the desired target or source file.</p> <p>Click the "Next" button.</p>	
3.	<p>The "WinCC Web Publishing Wizard – Select pictures" dialog field opens up.</p> <p>Select all pictures you want to publish. We generally recommend to publish all standard pictures.</p> <p>Via the ">>", "<<", ">" and "<" buttons you can select the pictures.</p> <p>Click the "Next" button.</p>	
4.	<p>The "WinCC Web Publishing Wizard – Select functions" dialog field opens up.</p> <p>Select all functions you want to publish. Only the scripts which were selected in the last publishing process are available in the pictures. This is why you select all necessary function for each publishing process.</p> <p>Via the ">>", "<<", ">" and "<" buttons you can select the functions.</p> <p>Click the "Next" button.</p>	

Step	Action	Note
5.	<p>The "WinCC Web Publishing Wizard – Referenced Graphics" dialog field opens up. Select all graphics you want to publish. We generally recommend to publish all graphics. Via the ">>", "<<", ">" and "<" buttons you can select the graphics. Click the "Next" button.</p>	
6.	<p>The "WinCC Web Publishing Wizard – Finish" dialog field opens up. Click the "Finish" button.</p>	
7.	<p>Pictures and functions which contain faulty scripts are marked with a red cross. Double-click each faulty picture to open and correct the picture in the "PdIPad" editor. Confirm the message after each publishing process by clicking the "OK" button.</p>	

Step	Action	Note
8.	<p>The transferred pictures are listed in the "WinCC Web Publishing Wizard – Finish" dialog field.</p> <p>Click the "Finish" button.</p>	
9.	<p>The published pictures are displayed in the data window of the Web Navigator.</p>	



7.4.2 Setting of User Rights, Website Start Screen and Language

Access restriction

Accesses of the Web clients on the OS Web server are controlled via user rights. User rights are assigned in the "User Administrator" editor. The user rights correspond to those of the standard clients.

Settings in the "User Administrator" Editor

Table 7-5

Step	Action	Note																																																
1.	<p>Open the "User administration" in the opened OS project of the WinCC Explorer.</p> <p>Create new users and/or new user groups and assign them respective authorizations.</p> <p>In addition, enable the option "WebNavigator" for the user/user group and enter the "Start Picture" and "Language" in the respective input fields.</p>	 <table border="1"> <thead> <tr> <th>No.</th> <th>Function</th> <th>Authorization</th> <th>Terminator(1)</th> </tr> </thead> <tbody> <tr><td>1</td><td>User administration</td><td>✗</td><td>✗</td></tr> <tr><td>2</td><td>Authorization for area</td><td>✗</td><td>✗</td></tr> <tr><td>3</td><td>System change</td><td>✗</td><td>✗</td></tr> <tr><td>4</td><td>Monitoring</td><td>✗</td><td>✗</td></tr> <tr><td>5</td><td>Process controlling</td><td>✗</td><td>✗</td></tr> <tr><td>6</td><td>Higher process controlling</td><td>✗</td><td>✗</td></tr> <tr><td>7</td><td>Report system</td><td>✗</td><td>✗</td></tr> <tr><td>100</td><td>Web Access monitoring only</td><td>✗</td><td>✗</td></tr> <tr><td>110</td><td>Highlevel process controlling</td><td>✗</td><td>✗</td></tr> <tr><td>115</td><td>Advanced operation 1</td><td>✗</td><td>✗</td></tr> <tr><td>116</td><td>Advanced operation 2</td><td>✗</td><td>✗</td></tr> </tbody> </table>	No.	Function	Authorization	Terminator(1)	1	User administration	✗	✗	2	Authorization for area	✗	✗	3	System change	✗	✗	4	Monitoring	✗	✗	5	Process controlling	✗	✗	6	Higher process controlling	✗	✗	7	Report system	✗	✗	100	Web Access monitoring only	✗	✗	110	Highlevel process controlling	✗	✗	115	Advanced operation 1	✗	✗	116	Advanced operation 2	✗	✗
No.	Function	Authorization	Terminator(1)																																															
1	User administration	✗	✗																																															
2	Authorization for area	✗	✗																																															
3	System change	✗	✗																																															
4	Monitoring	✗	✗																																															
5	Process controlling	✗	✗																																															
6	Higher process controlling	✗	✗																																															
7	Report system	✗	✗																																															
100	Web Access monitoring only	✗	✗																																															
110	Highlevel process controlling	✗	✗																																															
115	Advanced operation 1	✗	✗																																															
116	Advanced operation 2	✗	✗																																															
2.	<p>Select the start picture from the published graphics via the "... " button.</p> <p>"...\OS Web Server\<wincc name>\web="" navigator\pictures"<="" p="" project="" release=""> <p>Select the "@screen.pd_" graphic as start picture.</p> <p>Confirm your selection with the "Open" button.</p> <p>This is also how you determine a language for the control and monitor interface of the Web clients. To do this, click the respective "... " button.</p> <p>Confirm your selection with the "OK" button.</p> </wincc></p>																																																	
3.	Close the User Administration editor.																																																	

7.4.3 Configuring with the Web Configurator

Tasks of the Web Configurator

The Web Configurator sets up and manages the Internet Information Service (IIS) and therefore the website of the OS Web server. This setup is carried out on the Web server after you have loaded the project on the Web server. This setup and configuration is necessary to set up an operator station (OS) as OS Web server and to make it accessible for Web clients via the Intranet/Internet.

With the Web Configurator you can make the necessary firewall settings for the network card, if the firewall is enabled.

Requirements of the stand-alone system

- PCS 7 Web server software is installed on the stand-alone system
- the OS project is loaded on the stand-alone system
- settings in the OS are completed
- pictures, functions and graphics have been published
- user rights have been assigned/created





NOTE





Further information regarding the setup of a standard website can be found in the manual:

- [“SIMATIC Process Control System PCS 7 Web Option for OS \(V8.0\)”](#)
(chapter „Completing configuration on the OS Web server“)

Settings in the "Web Navigator" editor

Table 7-6

Step	Action	Note
1.	<p>Open the OS project on the OS Web server in the WinCC Explorer.</p> <p>Select the command "Web Configurator" via the context menu of the "Web Navigator" editor.</p> <p>The "WinCC Web Configurator" dialog field opens up.</p> <p>Click the "Next" button.</p>	
2.	<p>In the next window select the option "Create a new standard web site (stand-alone)".</p> <p>Click the "Next" button.</p>	
3.	<p>Specify a name for your web site in the "Name of web site" input field.</p> <p>Also assign the IP address and the connection port of the computer via the "Port" and "IP Address" input fields.</p> <p>Select "MainControl" from the drop-down list of the "Default web-Page" input field.</p> <p>Also enter a time in the "Reconnect Interval" input field</p> <p>Enable the option "Start the web-site after being configured".</p> <p>Click the "Next" button.</p>	
4.	<p>If the Windows-Firewall is not enabled, continue with step 8.</p> <p>Otherwise click the "Windows-Firewall" button (the button is only visible when the Firewall is enabled).</p>	

Step	Action	Note
5.	In the "Windows-Firewall" dialog field select the "Advanced settings" tab.	
6.	Make sure that the inbound rule „World Wide Web Services (HTTP Traffic-In)“ is activated. If deactivated, select the function and click on “Activate” in the context menu.	
7.	Click the "Finish" button.	
8.	Click the "OK" button. Afterwards close the WinCC Explorer and restart your computer to accept all settings.	

7.4.4 Loading and Compiling of Web server

Loading of Web server

Since the OS Web server is a stand-alone system (ES/OS/Web server), a loading and/or delta download of project data is not necessary because local data is already present through "Compile OS".

Compiling

The "Compile changes" function can be carried out for stand-alone systems without having to interrupt the process operation of the Web server.

NOTE

Further information regarding the configuration of the OS Web server can be found in the manual:



- [SIMATIC Process Control System PCS 7 OS Web Option](#)
(chapter "Configuration of the OS Web server on an ES")


7.5 Settings on Web client

Settings of web content zone "Internet" or "Local Intranet"

You have to make or check the settings for the web content page in the Internet Explorer to be able to install the plug-ins for the Web client of the OS Web server later.




Table 7-7



Step	Action	Note
1.	Open the Internet Explorer. Select the command "Tools > Internet Options"	
2.	Click the "Security" tab. Select the web content zone in which the Web server is located ("Internet" or "Local intranet"). Click the "Custom level..." button.	

Step	Action	Note
3.	Enable the option under "Execute ActiveX controls safe for scripting" and "Download signed ActiveX controls"	
4.	Click the respective "OK" buttons for the dialog fields "Security Settings" and "Internet Options" to close them.	

Settings of web content zone "Trusted sites"

Table 7-8

Step	Action	Note
1.	Open the Internet Explorer. Select the command "Tools > Internet Options".	
2.	Click the "Security" tab. Select the web content zone "Trusted sites". Click "Sites" to open the dialog field.	
3.	Enter the address of the OS Web server in the "Add this website to the zone" input field e.g. *://172.61.0.1 or http://*.microsoft.com Additionally, disable the option "Require server verification (https:) for all sites in zone". Click the "Add" and "Close" buttons.	

Step	Action	Note
4.	Select the web content zone "Trusted sites". Click the "Default level" and afterwards the "Custom level..." button.	 <p>The screenshot shows the 'Internet Options' dialog box with the 'Security' tab selected. Under 'Select a zone to view or change security settings.', the 'Trusted sites' zone is highlighted with a green checkmark. Below, the 'Trusted sites' section shows a description and a 'Security level for this zone' slider set to 'Medium'. The 'Enable Protected Mode' checkbox is unchecked. Buttons for 'Custom level...', 'Default level', and 'Reset all zones to default level' are visible.</p>
5.	Enable the option "Initialize and script ActiveX controls not marked as safe for scripting" in the dialog field "Security Settings".	 <p>The screenshot shows the 'Security Settings - Trusted Sites Zone' dialog box. The 'Settings' list has 'Initialize and script ActiveX controls not marked as safe for scripting' selected, with the 'Enable' radio button chosen. Other settings like 'Only allow approved domains to use ActiveX without prompt', 'Run ActiveX controls and plug-ins', and 'Script ActiveX controls marked safe for scripting*' are also visible with their respective radio buttons.</p>
6.	Click the respective "OK" buttons for the dialog fields "Security Settings" and "Internet Options" to close them.	

Therefore the requirements for a connection of Web client to Web server have been created.

7.6 Installation of Web client plugins

Installation paths

When installing the plugins for the Internet Explorer you can choose between two installation paths:

- Remote installation – installation via the Intranet/Internet of the Web server
- Local installation – installation via the Windows Installer Package of the Web client



In application example we look at the "Remote installation".




Requirements

- The OS Web server is in runtime.
- The Web client has access to the Web server.
- You know the Web server address.
- You know the domain, user name and password.
- The user authorizations are valid for PCS 7 Web Options.
- The login on the PC has the rights of a main user.

Installation

Table 7-9

Step	Action	Note
1.	Open the Internet Explorer. Enter the Web server address (http://<Server name or IP>) in the "Address" input field.	
2.	Enter the access data in the "Connect to <servername>" dialog field which was determined on the Web server in the "User Administrator" editor.	

Step	Action	Note																																													
3.	During the first connection the "Security Warning" dialog field will open up. Continue by clicking the "Install" button.	 The image shows a security warning dialog box from Internet Explorer. It asks "Do you want to install this software?" and provides details: Name: WebClientInstall.dll, Publisher: SIEMENS AG. There are "More options", "Install", and "Don't Install" buttons. A warning icon and text at the bottom state: "While files from the Internet can be useful, this file type can potentially harm your computer. Only install software from publishers you trust. What's the risk?"																																													
4.	Now all available plugins for the Web client will be displayed in the Internet Explorer window. In the "Install" column, click the arrow before the version number to install the plugin. The plugins: <ul style="list-style-type: none"> WinCC Basic Process Control WinCC Basic Process Control PCS 7 Faceplates PCS 7 Advanced Faceplates should be installed to guarantee minimum process control. During installation the displayed sequence is to be observed.	 The image shows a web browser window displaying a list of plugins for download/installation. The table lists components, their sizes, status, and versions. The status for all listed items is "Nicht installiert". <table border="1"> <thead> <tr> <th>Komponente</th> <th>Größe</th> <th>Status</th> <th>Version</th> <th>Installieren</th> </tr> </thead> <tbody> <tr> <td>Microsoft MSXML 6.0 required for SIMATIC BATCH WinCC Options</td> <td>1,492 K</td> <td>Nicht installiert</td> <td>6.0.3883.0</td> <td>[Arrow]</td> </tr> <tr> <td>PCS 7 Advanced Faceplates Web Components for PCS 7 Advanced Faceplates</td> <td>843 K</td> <td>Nicht installiert</td> <td>8.0.0.1</td> <td>[Arrow]</td> </tr> <tr> <td>PCS 7 Basic Faceplates Web Components for PCS 7 Basic Faceplates</td> <td>1,021 K</td> <td>Nicht installiert</td> <td>8.0.0.1</td> <td>[Arrow]</td> </tr> <tr> <td>SIMATIC BATCH WinCC Options Web Components for SIMATIC BATCH WinCC Options (requires Microsoft MSXML 6.0)</td> <td>3,066 K</td> <td>Nicht installiert</td> <td>8.0.0.1</td> <td>[Arrow]</td> </tr> <tr> <td>SIMATIC ES Common Services Web Components for SIMATIC ES Common Services</td> <td>858 K</td> <td>Nicht installiert</td> <td>8.0.0.0</td> <td>[Arrow]</td> </tr> <tr> <td>SIMATIC Route Control Web Components for SIMATIC Route Control Faceplate</td> <td>1,085 K</td> <td>Nicht installiert</td> <td>8.0.0.1</td> <td>[Arrow]</td> </tr> <tr> <td>SIMATIC SEC Common Displays Web Components for SIMATIC SEC Common Displays</td> <td>1,185 K</td> <td>Nicht installiert</td> <td>8.0.0.0</td> <td>[Arrow]</td> </tr> <tr> <td>SIMATIC 3D Visualization</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Komponente	Größe	Status	Version	Installieren	Microsoft MSXML 6.0 required for SIMATIC BATCH WinCC Options	1,492 K	Nicht installiert	6.0.3883.0	[Arrow]	PCS 7 Advanced Faceplates Web Components for PCS 7 Advanced Faceplates	843 K	Nicht installiert	8.0.0.1	[Arrow]	PCS 7 Basic Faceplates Web Components for PCS 7 Basic Faceplates	1,021 K	Nicht installiert	8.0.0.1	[Arrow]	SIMATIC BATCH WinCC Options Web Components for SIMATIC BATCH WinCC Options (requires Microsoft MSXML 6.0)	3,066 K	Nicht installiert	8.0.0.1	[Arrow]	SIMATIC ES Common Services Web Components for SIMATIC ES Common Services	858 K	Nicht installiert	8.0.0.0	[Arrow]	SIMATIC Route Control Web Components for SIMATIC Route Control Faceplate	1,085 K	Nicht installiert	8.0.0.1	[Arrow]	SIMATIC SEC Common Displays Web Components for SIMATIC SEC Common Displays	1,185 K	Nicht installiert	8.0.0.0	[Arrow]	SIMATIC 3D Visualization				
Komponente	Größe	Status	Version	Installieren																																											
Microsoft MSXML 6.0 required for SIMATIC BATCH WinCC Options	1,492 K	Nicht installiert	6.0.3883.0	[Arrow]																																											
PCS 7 Advanced Faceplates Web Components for PCS 7 Advanced Faceplates	843 K	Nicht installiert	8.0.0.1	[Arrow]																																											
PCS 7 Basic Faceplates Web Components for PCS 7 Basic Faceplates	1,021 K	Nicht installiert	8.0.0.1	[Arrow]																																											
SIMATIC BATCH WinCC Options Web Components for SIMATIC BATCH WinCC Options (requires Microsoft MSXML 6.0)	3,066 K	Nicht installiert	8.0.0.1	[Arrow]																																											
SIMATIC ES Common Services Web Components for SIMATIC ES Common Services	858 K	Nicht installiert	8.0.0.0	[Arrow]																																											
SIMATIC Route Control Web Components for SIMATIC Route Control Faceplate	1,085 K	Nicht installiert	8.0.0.1	[Arrow]																																											
SIMATIC SEC Common Displays Web Components for SIMATIC SEC Common Displays	1,185 K	Nicht installiert	8.0.0.0	[Arrow]																																											
SIMATIC 3D Visualization																																															
5.	Installation of the Web client is complete. Close the Internet Explorer and reopen it to register for process control. As soon as the Web client has established a connection with the Web server, the process pictures can be called.	 The image shows the SIMATIC Manager software interface. It displays a process control diagram for "Plant Section RMT1". The diagram includes various components like "RMT1", "RMT2", "RMT3", and "RMT4" connected to "Reaktor 1" and "Reaktor 2". The interface also shows a "Process Control" window with a "Field Task" and a "Command Input" section.																																													

Note

Further information regarding the installation of the Web client, process control on the Web client and settings can be found in the manual:

- [SIMATIC Process Control System PCS 7 OS Web Option](#)
(chapter "Installation and Settings for the Web client")

8 History

Table 8-1

Version	Date	Change
V1.0	10/2006	First release V6.1 SP1
V1.1	11/2006	Revision V6.1 SP1
V1.2	05/2009	Revision V6.1 SP1
V2.1	09/2008	First release V7.0 SP1
V2.2	12/2008	Correction in table 6-2
V2.3	05/2009	Revision V7.0 SP1
V3.0	05/2009	First release V7.1
V3.1	05/2009	Revision V7.1
V3.2	11/2009	Expansion of the documentation to V7.1 by the PCS 7 Web Option (tested for PCS 7 V7.1 and V7.0 SP2)
V2.4	12/2010	Notice inserted: In PCS 7 V7.0 SP3 the configuration, which is described in chapter 5 „ES/OS-Master and OS-Standby“ only works only with WinCC V6.2 SP3 HF8 or higher.
V3.3	09/2011	Notice inserted: In PCS 7 V7.1 SP2 and SP3 the configuration, which is described in chapter 5 „ES/OS-Master and OS-Standby“ only works with WinCC V7.0 SP2 HF5 or higher.
V4.0	10/2012	First release V8.0 Upd1
V4.1	11/2012	Modified chapters: <ul style="list-style-type: none"> Chapter 7 “Expansion by PCS 7 Web Option” Chapter 7.1 “Web Configuration” Chapter 7.2 “Web-Specific Hardware and Software Requirements” New Chapter: <ul style="list-style-type: none"> Chapter 7.3 “Maximal number of Web client accesses”
V4.2	01/2013	Introduction of the chapter 6 “ES/OS-Master and OS-Standby“ is modified.
V4.3	05/2013	Test and declaration for PCS7 V8.0 SP1
V4.4	09/2013	Modified information about the needed licenses in chapter 7.1 “Web Configurations” in the figure 7-1 “Web Option Configuration in stand-alone system”